



LEOPARD FAMILY

TL Leopard Series Transmitter and Controller

An economically smart programmable transmitter relay with isolated 4 to 20 mA retransmission or control loop output capability for measurement and control applications.



Optional Remote Display Programmer

General Features

- External transmitters or signal conditioners can be eliminated by direct connection of the sensor output to more than 38 Plug-in Input Signal Conditioners that include:
 - AC/DC Current – Pressure – Resistance
 - AC/DC Voltage – Process – *Temperature
 - Load Cell – Prototype – 4 to 20 mA
- *See models TLH for higher accuracy digitally linearized thermocouple and RTD
- Isolated 16 bit analog output. User or factory scalable to 4 to 20 mA, 0 to 20 mA or 0 to 10 V across any desired digital span from ± one count to the full scale range of – 1999 to 9999 (12000 counts).
- Auto-sensing AC/DC power supply. For voltages between **85-265 V AC / 95-300 V DC (PS1)** or 15-48 V AC / 10-72 V DC (PS2).
- 24 V DC excitation is available to power external transmitters and 5 or 10 V DC excitation is available for resistance bridge type sensors such as Load Cells and Pressure Transducers.
- Automatic intelligent averaging smooths noisy signals, while providing a fast display response to real level changes.
- Remote Display Option only.

Software Features

- Three-button programming from the optional remote display (UP, DOWN and PROGRAM buttons).
- Front panel selectable four-level brightness control of digital display, and setpoint LEDs when display is used.
- Two programmable setpoints.
- Relay activation can be selected to occur above (HI) or below (LO) each setpoint.
- Hysteresis, Delay on make and delay on break for both setpoints.
- Peak and Valley. View and Reset.(only when display is used)

Input Module Compatibility

LEOPARD FAMILY: More than 38 different Plug-in **I-Series** Input Signal Conditioners are approved for Texmate's Leopard Family of meters. Some examples are shown on pages 8-10. See www.texmate.com for an up to date listing.



LEOPARD

Specifications

Input Specs: Depends on Input signal conditioner
A/D Converter: 14 bit single slope
Accuracy: ±(0.05% of reading + 2 counts)
Temp. Coeff.: 100 ppm/°C (Typical)
Warm up time: 2 minutes
Conversion Rate: 5 conversions per second (Typical)
Remote Display: **4 digit 0.56" Red LED Remote display. (Optional)**
 Range –1999 to 9999 counts.
Polarity: Assumed positive. Displays – negative
Decimal Selection: Front panel button selectable, X•X•X•X•
Positive Overrange: Top segments of digital display flash
Negative Overrange: Bottom segments of digital display flash
Relay Output: Two 9 Amp Form C relays.
Analog Output: Isolated 16 bit user scalable mA or V
 AIC (mA out) 4-20 mA @ 0 to 500Ω max loop resistance
 AIV (volts out) 0-10 V DC @ 500 Ω or higher resistance
Power Supply: AC/DC Auto sensing wide range supply
PS1 (std) **85-265 VAC 50-400Hz / 95-300 VDC @ 3.5W**
PS2 15-48 VAC 50-400Hz / 10-72 VDC @ 3.5W
Operating Temp.: 0 to 50 °C
Storage Temp.: –20 °C to 70 °C.
Relative Humidity: 95% (non condensing)
Case Dimensions: DIN Rail Mount
 22.5mm x 102.4mm x 128.7mm
 (Width x Height x Depth)
 Plus 11.8 mm (0.47") for Right-angled connectors.
Weight: 7.5 oz., 9.0 oz when packed

Index

Case Dimensions	12	Digital Span Selection for Analog Range Output	5	I-Series Input Signal Conditioning Modules	8-10	Software Logic Tree	3
Connector Pinouts	7	Functional Diagram	7	Installation Guidelines	13	Specifications	1
Controls and Indicators	2	General Features	1	Ordering Information	14	Two Point Analog Output Range Setting and Calibration	5
Decimal Point & Brightness Selection	5	Glossary of Prog. Symbols	2	Setpoint Setting & Relay Configuration Mode	6		
Digital Calibration Mode	4	Input Module Analog Cal.	11-12	Software Features	1		
Digital Calibration Procedure	4	Input Module Comp. Glossary	11				
		Input Module Compatibility	1				

Optional Remote Display for Field Programming and Setup is needed



Front Panel Buttons

Program Button

The **P** button is used to move from one program step to the next. When pressed at the same time as the **↑** button, it initiates the **calibration mode**. When pressed at the same time as the **↓** button, it initiates the **setpoint setting mode**.

Up Button

When in the operational display, pressing the **↑** button alone, allows you to view and reset the Peak and Valley (Highest and Lowest Readings.)

When in the **calibration mode** or the **setpoint setting mode** the **↑** button is used to increase the value of the displayed parameter.

Down Button


When in the operational display, pressing the **↓** button alone, allows you to view, but not change, the setting of setpoint 1&2.

When in the **calibration mode** or the **setpoint setting mode** the **↓** button is used to decrease the value of the displayed parameter.


Glossary of Programming Symbols

To explain software programming procedures, logic diagrams are used to visually assist in following the programming steps. The following symbols are used to represent various functions and associated display elements of the meter:

Symbol	Explanation
	This symbol represents the OPERATIONAL DISPLAY.
	This is the PROGRAM button.
	This is the UP button.
	This is the DOWN button.
	When a button is shown, press and release it to go onto the next step in the direction indicated by the arrow. When two or more buttons are shown, each with an arrow, this indicates that there is a number of programming choices.
	When two buttons are shown side by side and enclosed by a dotted line, they must be pressed at the same time then released to go onto the next programming step.
	If the display is shown with XXXX it means the value displayed will be the previously set value. When a number is shown it indicates the initial factory default setting or a specific "example number".



When two displays are shown together with bursts, this indicates that the display is toggling (flashing) between the name of the function and the value.




Text or numbers shown between square brackets in a procedure indicate the programming code name of the function or the value displayed on the meter display.



When the **↑** and **↓** buttons are shown together, the display value can be increased by pressing and releasing the **↑** button or decreased by pressing and releasing the **↓** button.




When the **↑** and **↓** buttons are shown with two displays, either display can be selected by pressing and releasing the **↑** or **↓** buttons.



When there are more than two display selections they are shown in brackets below the first display and are also selectable by pressing and releasing the **↑** or **↓** buttons.

The TL is an intelligent transmitter with a hierarchical software structure designed for easy programming and operation, as shown below in the software logic tree.

After the meter has been powered up, the four digits light up for three seconds and then settle to the operational display indicating the input signal.



Pump On Pump Off
When PUM is selected ON, and SP2 is set at a value higher than SP1, the SP1 relay will operate in a special "pump on pump off" Hysteresis mode. SP2 acts as the upper limit and SP1 acts as the lower limit of the Hysteresis Band.

For filling applications, rLYS should be set to LhLh. SP1 will then activate for inputs less than the SP1 setpoint, and remain ON until the SP2 setpoint is reached.

For emptying applications, rLYS should be set to hhhh. SP1 will then activate for inputs greater than the SP2 setpoint, and remain ON until the SP1 setpoint is reached.

15 Second Program Timeout

The meter has a 15 second program timeout. If no buttons are pressed for 15 seconds, at any stage of the programming sequence the meter will exit the programming mode and return to the operational display. Any program changes that were made prior to pressing the [P] button in the preceding step will not be saved.

Digital Calibration Mode

This mode enables the meter to be calibrated with an automatic scale factor calculation, by applying a high input signal, entering the desired reading for that signal, then applying a zero or low input signal, and then entering the desired 0 or low reading. The meter then automatically calculates and programs in the requisite scale factor, within the following parameters.

1. Positive and negative signals may be applied, but the difference between the high and the low signal inputs must be at least 1000 counts or Err will be indicated.
2. Positive and Negative values for the desired reading can be entered, but the scale factor created can not exceed the Digital Display Span capability of the meter which is 12,000 counts between -1999 to 9999.
3. The internal Signal Span is limited to 3 V DC between -1 V DC to +2 V DC. Any outputs from an Input Signal Conditioning module that exceed these limits will cause the meter to indicate overrange regardless of the Digital Display Span scaled.

Note: Most input signal conditioners have provisions for analog calibration and scaling. If the meter's digital scale factor is set to read zero with a zero input (shorted input), and to read 1000 with a 1.000 V input, any pre-calibrated signal conditioner with an output that does not exceed -1 V to +2 V, will read correctly in the meter without any further calibration.

Digital Calibration Procedure

STEP A Enter the Calibration Mode

- 1) Press the **P** and **↑** buttons at the same time. Display toggles between [cAL] and [oFF].
- 2) Press the **↑** or **↓** button. Display changes from [oFF] to [on].
- 3) Press the **P** button. Display toggles between [ZEro] and the previous zero setting.

STEP B Select Between Two Point Digital Calibration of Input Signal and Two Point Analog Output

Note: If the analog output option is not present, Step B is skipped and the program goes directly from Step A to Step C.

- 1) Press the **↑** or **↓** button to select the display toggling from [cAL] to [iP] input calibration.
- 2) Press the **P** button. Display toggles between [ZEro] and the previous zero setting.

STEP C Set the Meter's Low Input Signal Reading on the Digital Display

- 1) Apply a zero or low signal to the meter. (Positive or negative values are allowed)
- 2) Using the **↑** and **↓** buttons, adjust the meter display to the desired reading for the applied low input signal.
- 3) Press the **P** button. Display toggles between [SPAN] and the previous span setting.

STEP D Set the Meter's High Input Signal Reading on the Digital Display

- 1) Apply a high input signal to the meter.
- 2) Using the **↑** and **↓** buttons, adjust the digital display to the desired reading for the applied high input signal.
- 3) Press the **P** button.

The Digital Calibration Procedure Mode is Now Complete.


If the digital calibration was successfully completed, the menu branches to the DISPLAY FUNCTION CONFIGURATION MODE, (see page 7) and the display flashes [dP] and the previous setting.

ERROR Indicates Unsuccessful Calibration

If the calibration was unsuccessful, the display indicates [Err], the new calibration settings just entered will not take effect and the previously stored setting will remain.

The three most likely causes of an error during calibration are:

- 1) The full scale and zero signals were too similar. The full scale signal must be at least 1000 counts greater than the zero or low input signal (positive and negative values are allowed).
- 2) The scaling requirement exceeded the capability of the meter (-1999 to 9999).
- 3) No input signal present, or incorrect connections.



Two Point Analog Output Range Setting and Calibration

STEP A Enter the Calibration Mode

- 1) Press the **P** and **↕** buttons at the same time.
Display toggles between [cAL] and [oFF].
- 2) Press the **↕** or **↗** button. Display changes from [oFF] to [on].
- 3) Press the **P** button. Display toggles between [cAL] and [out] input calibration.

STEP B Enter the Analog [oUT] Output Mode

- 1) Press the **P** button. Display toggles between [cLo] and an internal scale factor.


STEP C Set or Calibrate the [cLo] Low Analog Output Range

- 1) Select the voltage or current loop output header position on the output module. (See Component Layout on page 9).
- 2) Connect a multimeter to pins 16 and 17 on the output module. (See Connector Pinouts on page 7). Using the **↕** and **↗** buttons, adjust the analog output to the desired low value as shown on the multimeter display.
cLo may be adjusted to any value from -0.3 mA to 17 mA (mA output selected) or from -0.6 V to 8 V (volt output selected)
- 3) Press the **P** button. Display toggles between [chi] and an internal scale factor.

STEP D Set or Calibrate the [chi] High Analog Output Range

- 1) Using the **↕** and **↗** buttons, adjust the analog output to the desired high value as shown on the multimeter display. chi may be adjusted to any value from 17 mA to 21 mA (mA output selected) or from 8 V to 10.3 V (volt output selected)
- 2) Press the **P** button. The display exits the calibration mode and returns to the operational display.

Note: Having established the Low and High range of the analog output, the digital span can now be selected which will set the two digital points between which the analog output will occur. (See Digital Span Selection below).



Decimal Point and Brightness Selection

Enter the Decimal Point and Brightness Mode Through the Sub Menu [CAL] [oFF]

- 1) Press the **P** and **↕** buttons at the same time.
Display toggles between [cAL] and [oFF].
- 2) Press the **P** button. Display shows previous [dp] selection.

STEP E Set the Decimal Point

- 1) Using the **↕** and **↗**, adjust the display to the desired decimal point setting.
- 2) Press the **P** button. Display toggles between [Br] and the previous [Br] setting.

STEP F Set the Display Brightness

- 1) Using the **↕** and **↗** buttons, adjust the display to the desired brightness setting (4 is the brightest setting).
- 2) Press the **P** button. Display brightness changes to new setting and display toggles between [AnHi] and the previous [AnHi] setting.

Digital Span Selection for Analog Range Output

STEP G Setting the Digital Span Point for Analog High Output

- 1) Using the **↕** and **↗** buttons, adjust the display to the desired digital value which sets the point at which the selected analog high output range will occur.
- 2) Press the **P** button. Display toggles between [AnLo] and previous [AnLo] setting.

STEP H Setting the Digital Span Point for Analog Low Output

- 1) Using the **↕** and **↗** buttons, adjust the display to the desired digital value which sets the point at which the selected analog low output range will occur.
- 2) Press the **P** button. The display exits the calibration mode and returns to the operational display.

Note: Any two digital scale points from -1999 to 9999 can be selected. The digital scale points for analog high and analog low can be reversed for reversed 20-4 mA output. The span of the digital scale can be as small as two counts however small spans cause the 16 bit D to A to increment in stair case steps.

Setpoint Setting and Relay Configuration Mode

The following programming steps are required to enter the setpoint values and configure the relay functions in a meter with four relays using four setpoints. Generally if less than four relays are installed the software auto detects missing relays and deletes reference to them from the menu. In some cases setpoints without relays are operational for display only purposes.

STEP A Enter the Setpoint Mode

- 1) Press the **[P]** and **[↓]** buttons at the same time.
Display toggles between [SP1] and the previous [SP1] setting.

STEP B Set Setpoint 1 (SP1)

- 1) Using the **[↑]** and **[↓]** buttons, adjust the display to the desired SP1 value.
- 2) Press the **[P]** button. Display toggles between [doM] and the previous [doM] setting.

STEP C Set the SP1 Delay-on-Make (doM) Delay Time Setting

- 1) Using the **[↑]** and **[↓]** buttons, adjust the display to the desired [doM] value (0 to 9999 seconds). The reading must continuously remain in an alarm condition until this delay time has elapsed before the relay will make contact (energize).
- 2) Press the **[P]** button. Display toggles between [dob] and the previous [dob] setting.

STEP D Set the SP1 Delay-on-Break (dob) Delay Time Setting

- 1) Using the **[↑]** and **[↓]** buttons, adjust the display to the desired [dob] value (0 to 9999 seconds). The reading must continuously remain in a non-alarm condition until this delay time has elapsed before the relay will break contact (de-energize).
- 2) Press the **[P]** button. Display toggles between [hYSt] and the previous [hYSt] setting.

STEP E Set the Hysteresis Setting for Setpoint 1

- 1) Using the **[↑]** and **[↓]** buttons, adjust the display to the desired hysteresis [hYSt] value.
 - 2) Press the **[P]** button. Display toggles between [SP2] and the previous [SP2] setting.
- NOTE:** Half of the Hysteresis value selected is applied above and below the setpoint.

NOTE: Steps G, H, I and J have functionally the same procedure as steps B, C, D, and E shown above.

STEP F Select Pump [PUM] (on) or (off)

- 1) Using the **[↑]** and **[↓]** buttons, select the Pump to be ON or OFF. When PUM is selected ON, and SP2 is set at a value higher than SP1, the SP1 relay will operate in a special "pump on pump off" mode. SP2 acts as the upper limit and SP1 acts as the lower limit of the Hysteresis Band on the SP1 relay.

For filling applications:

[rLYS] should be set to [LhXX] (see step M). The SP1 relay and SP1 LED Annunciator will then activate for inputs less than the SP1 setpoint, and remain ON until the SP2 setpoint is reached.

For emptying applications:

[rLYS] should be set to [hhXX] (see step M). The SP1 relay and SP1 LED Annunciator will then activate for inputs greater than the SP2 setpoint, and remain ON until the SP1 setpoint is reached.

- 2) Press the **[P]** button. Display toggles between [SP2] and the previous SP2 setting.

STEP G Set Setpoint 2 (SP2)

STEP H Set the SP2 Delay-on-Make (doM) Delay Time Setting

STEP I Set the SP2 Delay-on-Break (dob) Delay Time Setting

STEP J Set the Hysteresis Setting for Setpoint 2

- 1) Using the **[↑]** and **[↓]** buttons, adjust the display to the desired hysteresis [hYSt] value.
- 2) Press the **[P]** button. Display toggles between [rLYS] and the previous relay setting.

STEP K Set Relay Activation mode [rLYS] for SP1

(h) High the relay energizes when the setpoint is exceeded. (L) Low the relay energizes below the setpoint. The setpoint is indicated from left to right SP1, SP2.


- 1) Using the **[↑]** and **[↓]** buttons, select (L) or (h) for the first digit, which corresponds to SP1.
- 2) Press the **[P]** button. The SP2 Relay Activation digit begins to flash, and its decimal point is lit.

STEP L Set High (h) or Low (L) for SP2


- 1) Using the **[↑]** and **[↓]** buttons, select (L) or (h) for the second digit, which corresponds to SP2.
- 2) Press the **[P]** button.

The transmitter exits the setpoint mode and return to the operational display.

The Setpoint Relay programming mode is now complete.



Functional Diagram



Connector Pinouts


Pinout Diagram

The Top and Bottom View of the transmitter diagram shows the transmitter with the relay configuration: Two 9 Amp Form C. An analog output module is also shown as installed.

The TL Series Transmitter uses plug-in type screw terminal connectors for all input and output connections. The power supply connections (pins 14 and 15) have a unique plug and socket outline to prevent cross connection. The main board and input signal conditioner use right-angled connectors as standard. The output module uses straight-thru connectors as standard.




WARNING: AC and DC input signals and power supply voltages can be hazardous. Do Not connect live wires to screw terminal plugs, and do not insert, remove or handle screw terminal plugs with live wires connected.



Auto-sensing AC/DC power supply. For voltages between 85-265 V AC / 95-300 V DC (PS1) or 15-48 V AC / 10-72 V DC (PS2).

Standard plug-in screw terminal connectors provided by Texmate:



Input Signal – Pins 1 to 6

Pins 1 to 6 are reserved for the input signal conditioner. See the data sheet for the selected input signal conditioner.

Relay Output Pins- Pins 8 to 13

Pin 8-10 SP1 Normally Open
 Pin 8-9 SP1 Normally Close
 Pin 11-13 SP2 Normally Open
 Pin 11-12 SP2 Normally Close

AC/DC Power Input- Pins 14 and 15

Auto-sensing AC/DC power supply. For voltages between 85-265 V AC/95-300 V DC (PS1) or 15-48 V AC/10-72 V DC (PS2).

Pin 14 AC/DC Neutral. Neutral power supply line.
 Pin 15 AC/DC line. Live power supply line.

Analog Output- Pins 16 and 18

Pins 16 and 17 are the analog output pins on the optional output module. Their pin definitions are:

Pin 16 Negative (-) analog output.
 Pin 17 Positive (+) analog output.
 Pin 18 Shield.










I-Series Input Signal Conditioning Modules

Many additional input modules are available and others are constantly being developed. Check with your local distributor or www.texmate.com for updated information.

Pre-calibrated **I-Series** input modules, that have span or zero potentiometers, can be interchanged between any **I-Series** compatible meter, without recalibration, because all of the analog scaling and reference circuitry is self-contained within the module. Where appropriate, all the standard ranges shown are designed to be header selectable by the user, and Texmate's unique SPAN ADJUST Header facilitates scaling to almost any required engineering unit. See Input Module Component Glossary and Calibration on pages 13 and 14. Also see Two Point Digital Calibration and Digital Calibration on page 4.

Unless otherwise specified Texmate will ship all modules pre-calibrated with factory preselected ranges and/or scalings as shown in **BOLD** type. Other pre-calibrated standard ranges or custom ranges may be ordered. Factory installed custom scaling and other custom options are also available (see Ordering Information, Special Options on last page).


Symbols Indicate Module Compatibility Within Meter Families

 TIGER Family	 LEOPARD Family	 LYNX Family
 TIGER Family	 LEOPARD Family	 LYNX Family
 TIGER Family	 LEOPARD Family	 LYNX Family
ALL MODELS	SOME MODELS	MODEL SPECIFIC




WARNING: AC and DC input signals and power supply voltages can be hazardous. Do Not insert, remove or handle modules with live wires connected to any terminal plugs.


IA01: AC Volts Scaled RMS, 200/300V AC




IA06: AC Volts True RMS, 300V AC




IA02: AC Volts Scaled RMS, 200mV/2V/20V AC




IA07: AC Volts True RMS, 200mV/2V/20V AC



IA03: AC Milliamps Scaled RMS, 2/20/200mA AC




IA08: AC Milliamps True RMS, 2/20/200mA AC




IA04: AC AC Amps Scaled RMS, 1 Amp AC

IA05: AC AC Amps Scaled RMS, 5 Amp AC




IA09: AC Amps True RMS, 1 Amp AC

IA11: AC Amps True RMS, 5 Amp AC




IA10: AC Millivolts, Scaled RMS, 100mV AC




I-Series Input Signal Conditioning Modules


IA12: AC Millivolt RMS Sigma Delta




ID01: DC Volts, 2/20/200V/Custom w/24V DC Exc



ID02: DC Millivolts, 20/50/100/200mV DC w/24V DC Exc




ID03: DC Milliamps, 2/20/200mA DC w/24V DC Exc




ID04: DC Amps, 5A DC


ID09: DC Amps, 1A DC



ID05: DC Volts 2/20/200/Custom V DC with Offset and 24V Exc.




ID07: DC Milliamps, 2/20/200mA DC with Offset and 24V Exc




IP01: Process Loop, 4-20mA

IP02: Process Loop, 4-20mA with 24VDC EXC




IP03: Process Input, 1-5V DC with Offset, 24V Exc




IP07: Universal Process Input


2V/5V/10V/20V/200V/2mA/20mA/Custom



IR02: 3 wire Potentiometer 1KΩ min (0-F.S.)




IR03: Linear Potentiometer 1KΩ min




I-Series Input Signal Conditioning Modules

IR04: Resistance 2KΩ (Lynx only)
IR05: Resistance 2KΩ (Leopard only)




IS01: Strain Gage 5/10V DC Exc., 20/2mV/V, 4/6-wire


IS02: Pressure/Load Cell 5/10V DC Exc., 20/2mV/V, 4/6-wire




IS04: Pressure/Load Cell Ext Exc., 20/2mV/V, 4/6-wire




IS05: Pressure/Load Cell 20/2mV/V, 5/10V Exc 4-wire




IS06: Pressure/Load Cell Ext Exc., 20/2mV/V, 4-wire



IS07: Pressure/Load Cell Ext Exc. High Impedance, 20/2mV/V, 4/6-wire






Input and Output Pins

On most modules Pin 1 is the Signal High input and Pin 3 is the Signal Low input. Typically Pin 2 is used for Excitation Voltage output.




24V DC Output Header

On some modules this header enables a 24V DC 25mA (max) Excitation/Auxiliary output to be connected to Pin 2.




INPUT RANGE Header

Range values are marked on the PCB. Typically two to four positions are provided, which are selected with either a single or multiple jumper clip. When provided, a custom range position is only functional when the option has been factory installed.



SPAN Potentiometer (Pot)


If provided, the 15 turn SPAN pot is always on the right side (as viewed from the rear of the meter). Typical adjustment is 20% of the input signal range.



SPAN ADJUST Header


This unique five-position header expands the adjustment range of the SPAN pot into five equal 20% steps, across 100% of the input Signal Span. Any input Signal Span can then be precisely scaled down to provide any required Digital Display span from 1999 counts to 001 (one count).

SPAN Adjust Header position	1	2	3	4	5
SPAN Pot %	20%	20%	20%	20%	20%
Signal Span %	20%	40%	60%	80%	100%





SPAN RANGE Header

When this header is provided it works in conjunction with the SPAN ADJUST Header by splitting its adjustment range into a Hi and a Lo range. This has the effect of dividing the adjustment range of the SPAN pot into ten equal 10% steps across 100% of the input Signal Span.




SPAN Adjust Header position	1	2	3	4	5	1	2	3	4	5
SPAN Pot %	10%	10%	10%	10%	10%	10%	10%	10%	10%	10%
Signal Span %	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%



ZERO Potentiometer (Pot)

If provided, the ZERO pot is always to the left of the SPAN pot (as viewed from the rear of the meter). Typically it enables the input signal to be offset $\pm 5\%$ of full scale (-100 to +100 counts).



ZERO OFFSET RANGE Header




When provided, this three position header increases the ZERO pot's capability to offset the input signal, to $\pm 25\%$ of the digital display span. For example a Negative offset enables a 1 to 5V input to display 0 to full scale. The user can select negative offset, positive offset, or no offset (ZERO pot disabled for two step non-interactive span and offset calibration).

ZERO Pot %	- 100% of Offset	0 No Offset	+ 100% of Offset
Offset Range	- 500 Counts	Zero Pot Disabled	+ 500 Counts



ZERO ADJUST Header



When this header is provided, it works in conjunction with the ZERO OFFSET RANGE Header, and expands the ZERO pot's offset capability into five equal negative steps or five equal positive steps. This enables virtually any degree of input signal offset required to display any desired engineering unit of measure.

ZERO Adjust Header position	5	4	3	2	1	1	2	3	4	5	
ZERO Pot %	-20%	-20%	-20%	-20%	-20%	0	+20%	+20%	+20%	+20%	
Offset Range	-1200 or more counts					Zero Pot Disabled	+1200 or more counts				



Input Module Analog Calibration

In addition to the analog calibration capabilities that enable many modules to be interchanged between different meters without loss of accuracy the Leopard Family of meters have enhanced Digital Calibration functions. See Page 4

Basic standard range calibration of direct reading modules that utilize either Auto Zero or a ZERO pot, an INPUT RANGE Header and or a SPAN pot.

- 1 If the module has an INPUT RANGE Header, reposition the jumper clip to select the desired input signal range.
2. Apply a zero input or short the input pins. The display will auto zero, or if the module has a ZERO pot, it should be adjusted until the display reads zero.
- 3 Apply a known input signal that is at least 20% of the full scale input range and adjust the SPAN pot until the display reads the exact input value. For negative inputs, Leopard Family Meters will display negative overrange at 50% of full scale range.
- 4 Decimal Points. The selection or positioning of decimal points has no effect on the calibration of the modules

Wide range scaling, in engineering units not requiring offsets, with modules that utilize auto-zero or a ZERO pot, a SPAN RANGE Header and or a SPAN ADJUST Header.

Texmate's unique SPAN ADJUST and SPAN RANGE Headers provide the circuit equivalent of an ultra-precision one megohm 75 or 150 turn potentiometer that can infinitely scale down any Input Signal SPAN to provide any full scale Digital Display Span from 1999 (counts) to 001 (one count).

If the module has an INPUT RANGE Header, and the required full

Input Module Calibration Procedures Continued

scale Digital Display Span (counts) is to be larger than the directly measured value of the input Signal Span, then the next lower range on the INPUT RANGE Header should be selected. The resulting over range Signal Span is then scaled down, by selecting the position of the SPAN RANGE Header and or the SPAN ADJUST Header, which will reduce the input Signal Span to a percentage, that the required Digital Display Span can be reached by calibration with the SPAN pot.

Example A: 0 to 10 V to read 0 to 1800 gallons.

Signal Span = 10V, Digital Display Span = 1800 counts

- 1 Select the 2 V INPUT RANGE Header position. This will provide a digital display of 1800 counts with an input of only 1.8 V which is $(1.8 \div 10) = 18\%$ of the examples 10 V Signal Span.
- 2 To scale down the Signal Span to 18% select the 20% Signal Span position on the SPAN ADJUST Header (position 1) or if the module has a SPAN RANGE Header, select (LO Range) and 20% Signal Span position on the SPAN ADJUST Header (position 2).
- 3 Apply a zero input or short the input pins. The display will auto zero, or if the module has a ZERO pot, it should be adjusted until the display reads zero.
- 4 Apply 10 V and adjust the SPAN pot until the display reads 1800.

Large offset scaling and calibration of process signal inputs with modules that utilize ZERO ADJUST Headers and or ZERO OFFSET RANGE Headers.

Texmate's unique ZERO OFFSET RANGE Header enables the use of a simple two step scaling and calibration procedure for those process signals that require large offsets. This eliminates the back and forth interaction, between zero and span settings, that is often required to calibrate less finely engineered products.

The first step is to set the ZERO OFFSET RANGE Header to the center position (No Offset) and scale down the Input Signal Span to a percentage that will enable calibration with the SPAN pot to reach the required Digital Display Span.

The second step is to set the ZERO ADJUST and or ZERO OFFSET RANGE Header to provide a positive or negative offset of sufficient counts that calibration with the ZERO pot will offset the Digital Display Span to produce the required digital reading.

Example B: 1 to 5 V to read -100 to 1500 °C.

Signal Span = 4V, Digital Display Span = 1600 counts


- 1 If the module has an INPUT RANGE Header the 2 V position should be selected. This will provide a digital display of 1600 counts for an input of 1.6 V which is $(1.6 \div 4) = 40\%$ of the examples 4 V signal span. To scale down the Signal Span to 40% select the 40% Signal Span position on the SPAN ADJUST Header (position 2).
- 2 If the module is a Process Input 1-5 V DC type, select the (Hi Range) position on the SPAN RANGE Header and the 100% Signal Span position on the SPAN ADJUST Header (position 5, max increase). This will provide a digital display of 1600 counts for an input of 4V which is 100% of the examples 4V Signal Span.
- 3 Set the ZERO OFFSET RANGE Header to the center position (no offset). Apply 1 V and adjust the SPAN pot until the display reads 400 . A 4V input would then read 1600 counts.
- 4 Set the ZERO OFFSET RANGE Header to the negative offset position. If the module has a ZERO ADJUST Header select the position that will provide a negative offset of ≈ -500 counts. Apply 1 V and adjust the ZERO pot until the display reads -100. Apply 5 V and check that the display reads 1500.

Example C: 4 to 20 mA to read 00.0 to +100.0%

Signal Span = 16 mA, Digital Display Span = 1000 counts.

- 1 The full scale Signal Span of the Process Input 4-20 mA modules is 0 to 20 mA for a full scale Digital Display Span of 0 to 2000 counts. This will provide a digital display of 1000 counts with an input of only 10 mA which is $(10 \div 16) = 62.5\%$ of the examples 16 mA signal span.
- 2 To scale down the Signal Span to 62.5% select the (Hi Range) Position on the Span Range Header and the 70% Signal Span position on the SPAN ADJUST Header (position 2).
- 3 Set the ZERO OFFSET RANGE Header to the center position (no offset). Apply 4 mA and adjust the SPAN pot until the display reads 250 . A 16 mA input would then read 1000 counts.
- 4 Set the ZERO OFFSET RANGE Header to the positive offset position. If the module has a ZERO ADJUST Header select the position that will provide a negative offset of ≈ -250 counts. Apply 4 mA and adjust the ZERO pot until the display reads 000. Apply 20 mA and check that the display reads 1000. Select decimal point XXX·X to display 00.0 to 100.0.

Case Dimensions




Installation

1. Install and wire transmitter per local applicable codes/regulations, the particular application, and good installation practices.
2. Install transmitter in a location that does not exceed the maximum operating temperature and that provides good air circulation.
3. Separate input/output leads from power lines to protect the transmitter from external noise. Input/output leads should be routed as far away as possible from contactors, control relays, transformers and other noisy components. Shielding cables for input/output leads is recommended with shield connection to earth ground near the meter preferred.
4. A circuit breaker or disconnect switch is required to disconnect power to the meter. The breaker/switch should be in close proximity to the meter and marked as the disconnecting device for the meter or meter circuit. The circuit breaker or wall switch must be rated for the applied voltage (e.g., 120VAC or 240VAC) and current appropriate for the electrical application (e.g., 15A or 20A).
5. See *Connector Pinouts section* for wiring.
6. Use 28-12 AWG wiring, minimum 90°C (HH) temperature rating. Strip wire approximately 0.3 in. (7-8 mm).
7. Recommended torque on all terminal plug screws is 4.5 lb-in (0.51 N-m).



Ordering Information



► BASE MODEL NUMBER

TL Standard Leopard Series Transmitter and Controller

► POWER SUPPLY

PS1 **85-265VAC/95-300VDC**
PS2 15-48VAC/10-72VDC

► INPUT MODULES

Unless otherwise specified Texmate will ship all modules precalibrated with factory preselected ranges and/or scalings as shown in **BOLD** type

IA01 . .AC-Volts Scaled RMS, 200/**300V AC**
IA02 . .AC-Volts Scaled RMS, 200mV/**2V/20V AC**
IA03 . .AC-mA Scaled RMS, 2/**20/200mA AC**
IA04 . .AC-Amps Scaled RMS, **0-1 Amp AC (0-100.00)**
IA05 . .AC-Amps Scaled RMS, **0-5 Amp AC (0-100.00)**
IA06 . .AC-Volts True RMS, 200/**300V AC**
IA07 . .AC-Volts True RMS, 200mV/**2V/20V AC**
IA08 . .AC-mA True RMS, 2/**20/200mA AC**
IA09 . .AC-Amps True RMS, **0-1 Amp AC (0-100.00)**
IA10 . .AC-Millivolt, Scaled RMS, **100mV AC**
IA11 . .AC-Amps True RMS, **0-5 Amp AC (0-100.00)**
IA12 . .AC-Millivolt, True RMS, **100mV AC**
ID01 . .DC-Volts, 2/20/200V/Custom w/24V DC Exc
ID02 . .DC-Millivolt, 20/50/**100/200mV DC w/24V DC Exc**
ID03 . .DC-Milliamp, 2/20/200mA DC w/24V DC Exc
ID04 . .DC-Amps, **5A DC**
ID05 . .DC-Volts 2/20/200/Custom V DC w/Offset and 24V Exc . .
ID07 . .DC-Milliamp, 2/20/200mA DC w/Offset and 24V Exc
ID09 . .DC-Amps, **1A DC**
IP01 . .Process Loop, **4-20mA(0-100.00)**
IP02 . .Process Loop, **4-20mA(0-100.00)** w/24VDC Exc
IP03 . .Process Input, **1-5V DC(0-100.00)** w/Offset, 24V Exc
IP07 . .Universal Process 2V/5V/**10V/20V/200V/2mA/20mA/Custom**
IR02 . .3-Wire Potentiometer 1K Ω min (0-F.S.)
IR03 . .Linear Potentiometer, 3-wire, 1K Ω min
IR05 . .Resistance 2K Ω
IS01 . .Strain Gage 5/10VDC Exc., 20/2mV/V, 4/6-wire
IS02 . .Pressure 5/10VDC Exc., 20/2mV/V, 4/6-wire
IS04 . .Pressure Ext Exc., 20/2mV/V, 4/6-wire
IS05 . .Pressure/Load Cell 20/2mV/V, 5/10V Exc 4-wire
IS06 . .Pressure/Load Cell Ext Exc., 20/2mV/V, 4-wire
IS07 . .Pressure 20/2mV/V with High Impedance and External Excitation

► ANALOG OUTPUT

OIC . . Isolated 16 Bit Current Output, 4-20mA
OIV . . Isolated 16 Bit Voltage Output, 0-10VDC

► RELAY OUTPUT

R11 . . Single 9A Form C Relay
R12 . . Dual 9A Form C Relays

SPECIAL OPTIONS

► SPECIAL OPTIONS

Range Change and Custom Scaling

Customer must specify the input signal range or digital span and the desired display range, or output signal range. Multiple inputs or multiple displays require a separate range change or custom scaling part number and a specified channel for each input or display.

Range Change and calibration to another header selectable standard range
CR-CHANGE . . Range Change from Standard Range shown in **BOLD** type

Output - Custom Scaling within standard ranges of analog output.
COA-3/3.5/4 . . Custom scaling of analog output

Short Depth 96x48 Remote Display/Programmer

OP-TL/RDISP . . Remote Display/Programmer w/Cable and Belt Clip Carrying Case

WARRANTY

Texmate warrants that its products are free from defects in material and workmanship under normal use and service for a period of one year from date of shipment. Texmate's obligations under this warranty are limited to replacement or repair, at its option, at its factory, of any of the products which shall, within the applicable period after shipment, be returned to Texmate's facility, transportation charges pre-paid, and which are, after examination, disclosed to the satisfaction of Texmate to be thus defective. The warranty shall not apply to any equipment which shall have been repaired or altered, except by Texmate, or which shall have been subjected to misuse, negligence, or accident. In no case shall Texmate's liability exceed the original purchase price. The aforementioned provisions do not extend the original warranty period of any product which has been either repaired or replaced by Texmate.

USER'S RESPONSIBILITY

We are pleased to offer suggestions on the use of our various products either by way of printed matter or through direct contact with our sales/application engineering staff. However, since we have no control over the use of our products once they are shipped, **NO WARRANTY WHETHER OF MERCHANTABILITY, FITNESS FOR PURPOSE, OR OTHERWISE** is made beyond the repair, replacement, or refund of purchase price at the sole discretion of Texmate. Users shall determine the suitability of the product for the intended application before using, and the users assume all risk and liability whatsoever in connection therewith, regardless of any of our suggestions or statements as to application or construction. In no event shall Texmate's liability, in law or otherwise, be in excess of the purchase price of the product.

Texmate cannot assume responsibility for any circuitry described. No circuit patent or software licenses are implied. Texmate reserves the right to change circuitry, operating software, specifications, and prices without notice at any time.

TEXMATE INC

450 State Place • Escondido, CA 92029

Tel: 1-760-598-9899 • USA 1-800-839-6283 • That's 1-800-TEXMATE

Fax: 1-760-598-9828 • Email: orders@texmate.com • Web: www.texmate.com

We have authorized distributors throughout the USA and in 28 other countries.

For product details visit www.texmate.com

Local Distributor Address