


## 16-BIT SMART 4-CHANNEL LOAD CELL MODULE

16-BIT SMART 4-CH LOAD CELL MODULE



IDC Shielded Cable.  
In user selectable lengths

16-pin Load Cell Terminal Block.  
Din rail mount.  
Up to 8 load cells,  
6-wire configuration.

Ultra-low noise 16-bit  
A/D Converter.  
Approaches 19-bit performance  
due to software filtering.

State-of-the-art  
Electromagnetic Noise  
Suppression Circuitry.  
Ensures signal integrity under harsh  
EMC environments.

On-board Digital Signal  
Processor.  
Choice of averaging and sample rates.  
4 Averaged output.

Interface to  
Tiger Meter.

The cost effective solution to monitoring up to eight load cells on four individual channels.

This input module and terminal block interface can receive multiple load cell inputs normally found on hoppers, tanks, bins, and silos and is ideally suited for level and inventory monitoring in the heavy weighing industry. With four averaged load cell inputs from the terminal block to a 16-bit A/D convertor in the input module, the ISS7 or ISS8 provides a diagnostic capability that allows damaged load cells to be quickly detected and repaired. In applications requiring weight measurement from different sources such as dry material handling, the input module can show how mass is distributed in a silo, or activate an alarm when wind loading exceeds a predetermined setting.

### Input Module Order Code Suffix

ISS7 (50 Hz Rejection)

ISS8 (60 Hz Rejection)



### Hardware Module Specifications

Excitation	5 V DC, 130 mA maximum.
Input Range	Software selectable for sensors from 1 mV/V to 20 mV/V.
Input Channels	Quad, independent gains. Zero X-talk between channels each having 19-bit effective resolution.
Input Sensitivity	0.08 $\mu$ V/Count maximum.
Zero Drift	$\pm$ 40 nV/ $^{\circ}$ C typical.
Span Drift	$\pm$ 5 ppm/ $^{\circ}$ C of full scale maximum.
Non-linearity	$\pm$ 0.003% of full scale maximum.
Input Noise	160 nVp-p typical at 1 Hz output rate.
Signal Processing Rate	10 Hz maximum, 0.5 Hz minimum.


### Software Module Features

Output Rates	A choice of average response outputs, 0.5-10 Hz.
Gain Select	Choice of industry standards, 1-20 mV/V.
Frequency Select	50 Hz (ISS7) / 60 Hz (ISS8) noise rejection.

### Some Relevant Tiger 320 Series Operating System Features

Auto Zero Maintenance.
Set TARE, Reset TARE.
Setpoint Timer Functions.
Setpoint Register Reset and Trigger Functions.
On-demand Calibration.
BASIC Compiler for PLC Functions.
32-Point Linearization.
Totalizator and Serial Printing.

### INPUTS



Quad Channel  
Load-cell  
Pressure

ISS7/8 is a 4-channel smart load cell input module that can provide excitation for a maximum of eight load cells. The input module can receive four independent sensor input signals through four channels from any combination of up to eight load cells.

Being a smart input module means that it can perform the following pre-processing functions on the input signals of all four channels, prior to processing in the Tiger 320 meter:

- Select the line frequency for all four inputs.
- Select the signal range for all four inputs.
- Select the averaged output rate for all four inputs.




Figure 1 – Up to Eight Load Cell Sensor Inputs into Four Input Module Channels

The preferred method of connecting load cells to the ISS7/8 input module is via the DIN rail mount terminal block. Unlike simple junction boxes that combine all load cell input signals into one sensor input prior to processing in a controller, the load cell terminal block can interface eight load cells into as many as four independent sensor groups. For example, sensor input 1 could have four load cells, sensor input 2 could have two load cells, sensor input 3 could have one load cell, and sensor input 4 could also have one load cell. This provides four averaged signals for pre-processing via the four channels of the input module's 16-bit A/D converter and built-in microprocessor.

### Diagnostic Capability

Having four independent inputs provides a diagnostic capability to quickly detect which sensor input is faulty. Using the meter's view modes, all four input channel readings can be quickly viewed. This allows incorrectly installed, connected, or damaged load cells to be quickly identified and then repaired.




Figure 2 – Viewing all Four Channels

## Weight Distribution Monitoring

Having four independent load cell inputs is also useful in the load distribution and wind loading areas of dry material handling. With individual inputs from each support on a silo, it is possible to detect uneven distribution of mass within the silo (See Figure 3). Wind loading is a potentially dangerous hazard with high silos, especially when empty. Setpoint alarms can be configured for each load cell to activate when the wind load exceeds a pre-set limit.




Figure 3 – Weight Distribution in Dry Material Silo

## Component Layout

See **Connecting Load Cells to the Input Module** for connection details




Figure 4 – ISS7/8 Input Module Component Layout

## Connecting Load Cells to the Input Module


Connecting the load cells directly to the input module is an option, but means that a maximum of only four load cells can be connected and processed. In most cases connecting through the terminal block simplifies connections and allows for up to eight load cells to be connected (See Figure 5).

The external pinouts between the input module and the terminal block are shown in the table opposite:



**The  $\pm$  sense connections are connected by jumper wires to the  $\pm$  excitation connections at the terminal block to minimize lead wire error. This is particularly important with multiple load cell operation.**

Input Module Pin No.	Function	Junction Block Pin No.	Label
1	Input 1	15	+1
2		16	-1
3	Input 2	13	+2
4		14	-2
5	Input 3	11	+3
6		12	-3
7	Input 4	09	+4
8		10	-4
9	+Sense	07	+S
10	-Sense	08	-S
11	+Exc	05	5 V
12	+Exc	06	5 V
13	-Exc	03	0 V
14	-Exc	04	0 V
15	Shield	01	Sh
16	n/c	02	-



See Figure 7 for details on connecting a single load cell to the terminal block






Figure 5 – Load Cell to Input Module Connections

Connection to the DIN rail mount terminal block and the input module is via a shielded 16-wire IDC cable available in user selectable lengths. For example, the Tiger 320 controller and input module could be sited about 5 meters from the load cells. In this case, the terminal block would be located close to the load cells and connected, by a 5 meter length of IDC cable, to the controller housed in an enclosure. Also, the controller could possibly be linked to a central control through a serial communications link (See Figure 6).



**Figure 6 – Example of Three Load Cells Connected to the Meter via the Terminal Block**

Alternatively, both the controller and the terminal block could be mounted on a DIN rail within an enclosure and connected using a standard short ribbon cable (See Figure 7).



**Figure 7 – Example of Single Load Cell Connected to the Meter via the Terminal Block**

## Smart Setup Registers

The meter uses three smart setup registers to configure smart input modules. ISS7 and ISS8 require **smart registers 1 and 2** to be set up.


This input module produces four output registers, each being the averaged result of one or more input sensors. One of these registers can be transferred to CH1 via Code 2, the same or another register transferred to CH2 via Code 4, the same or another register transferred to CH3 via Code 5, and the same or another register transferred to CH4 via Code 6.

Smart register 1 allows you to select the following settings:

- A line frequency of 50 or 60 Hz for all four sensor inputs.
- The input signal range for sensor input 1 only from 1, 2, 3, or 20 mV/V.
- And the output rate for all four sensor inputs from 0.5, 1, 5, or 10 Hz (Note: If more than one type of load cell is installed, the output rate selected must correspond to the load cell requiring the fastest output rate).

Smart register 2 allows you to select the input signal range for sensor inputs 2, 3, and 4.

### Smart Setup Register – Operational Flow Diagram



## Programming Procedures

**1** Press the **P** and **↑** buttons at the same time to enter the main programming mode.

**2** Press the **P** button three times to enter Code 2. Set Code 2 to [X77].

Cod\_2 | X77

This setting enters the **smart register 1** code setup menu.

FIRST DIGIT
<b>TIGER PROCESSING RATE</b>
0 10 Hz
1 10 Hz
2 100 Hz
3 100 Hz

SECOND DIGIT
<b>MEASUREMENT TASK</b>
0 Voltage, Current
1 TC (3rd digit selects type of TC)
2 RTD 3-wire (3rd digit selects type of RTD)
3 RTD 2- or 4-wire (3rd digit selects type of RTD)
4 Frequency
5 Period
6 Counter
7 Smart Input Module

THIRD DIGIT
<b>OUTPUT REGISTER MAP</b>
0 Averaged signal SENSOR 1
1 Averaged signal SENSOR 2
2 Averaged signal SENSOR 3
3 Averaged signal SENSOR 4
4 -
5 -
6 -
7 Smart input module register 1 code setup

**3** Press the **P** button.

577E | 000

This menu provides settings unique to **smart register 1** of input module ISS7/8.

FIRST DIGIT
<b>LINE FREQUENCY</b>
0 60 Hz rejection
1 -
2 50 Hz rejection
3 -

SECOND DIGIT
<b>SENSOR 1 INPUT mV/V (5 V Exc.)</b>
0 1 mV/V
1 2 mV/V
2 3 mV/V
3 20 mV/V
4 -
5 -
6 -
7 -

THIRD DIGIT
<b>OUTPUT RATE</b>
0 0.5 Hz averaged
1 1 Hz averaged
2 5 Hz averaged
3 10 Hz averaged
4 -
5 -
6 -
7 -



Note the output register map is different for each smart input module.

4 Using the buttons, select the relevant **line frequency** rejection for all input sensors, the input range of **sensor 1**, and the **output rate** common to all sensor inputs.

5 Press the button. The display returns to [Cod\_2] [X77].

6 Using the buttons, reset the 3rd digit in Code 2 to select an output register (sensor) from the output register map.

Note, **sensor 1** would normally be selected as the output register as this output is transferred to channel 1 in the meter.



**Note the output register map is different for each smart input module.**

7 Press the button 3 times to enter Code 5. Set Code 5 to [X77].

FIRST DIGIT	
<b>CH3 POST PROCESSING</b>	
0	Direct Display of Input (no processing)
1	Square Root of Channel 3
2	Inverse of Channel 3
3	<b>Meters with 4 kB memory</b> NO Linearization
	<b>Meters with 32 kB memory</b> 32-point Linearization of CH3 using Table 3
<i>Note: All linearization tables are set up in the Calibration Mode [24X].</i>	

SECOND DIGIT	
<b>MEASUREMENT TASK</b>	
0	No function
1	Voltage, current
2	TC
3	RTD
4	Real time clock & timer
5	-
6	-
7	Smart input module

THIRD DIGIT	
<b>OUTPUT REGISTER MAP</b>	
0	Averaged signal SENSOR 1
1	Averaged signal SENSOR 2
2	Averaged signal SENSOR 3
3	Averaged signal SENSOR 4
4	-
5	-
6	-
7	Smart input module register 1 code setup

8 Press the button.  
This setting enters the **smart register 2** code setup menu.



**Note the output registers in the 3rd digit are specific to ISS7/8. These registers vary for each different smart input module.**

FIRST DIGIT	
<b>SENSOR 4 Input Range</b>	
0	1 M
1	2 M
2	3 M
3	20 mV
4	-
5	-
6	-
7	-

SECOND DIGIT	
<b>SENSOR 3 Input Range</b>	
0	1 M
1	2 M
2	3 M
3	20 mV
4	-
5	-
6	-
7	-

THIRD DIGIT	
<b>SENSOR 2 Input Range</b>	
0	1 M
1	2 M
2	3 M
3	20 mV
4	-
5	-
6	-
7	-

9 Using the buttons, select the **sensor 4 input** from the 1st digit, select the **sensor 3 input** from the 2nd digit, and select the **sensor 2 input** from the 3rd digit.

10 Press the button to save the settings.  
The display toggles between [Cod\_5] and [X77].

11 Using the button, reset the 3rd digit to 0 to leave the smart register 2 menu.

12 Press the and buttons at the same time to return to the operational display.



# Select a Channel

Select the output register for the required channels

- 13 Press the **P** and **↑** button at the same time again to re-enter the main programming mode.
- 14 Press the **P** button three times to enter Code 2.
- 15 Set Code 2 to [X7X]. Select the required processing rate for **sensor 1** in the 1st digit and the required register map setting in the 3rd digit.



Note the output register map is different for each smart input module type.

**CH1** [Cod\_2] [X7X]

FIRST DIGIT	SECOND DIGIT	THIRD DIGIT
<b>TIGER PROCESSING RATE</b>	<b>MEASUREMENT TASK</b>	<b>OUTPUT REGISTER MAP</b>
0 10 Hz 1 10 Hz 2 100 Hz 3 100Hz	0 Voltage, Current 1 TC (3rd digit selects type of TC) 2 RTD 3-wire (3rd digit selects type of RTD) 3 RTD 2- or 4-wire (3rd digit selects type of RTD) 4 Frequency 5 Period 6 Counter 7 Smart Input Module	0 Averaged signal SENSOR 1 1 Averaged signal SENSOR 2 2 Averaged signal SENSOR 3 3 Averaged signal SENSOR 4 4 - 5 - 6 - 7 Smart input module register 1 code setup

- 16 If required enter Code 4 and select the required register map settings for **sensor 2** in the 2nd digit.  
**Note, the 1st and 3rd digits must be set to 0.**

**CH2** [Cod\_4] [0X0]

FIRST DIGIT	SECOND DIGIT
<b>MEASUREMENT TASK</b>	<b>FOR VOLTAGE &amp; CURRENT</b>
0 Voltage, Current 1 TC (type as per 2nd digit) 2 RTD (type as per 2nd digit) 3 Second Digital Input Channel (type as per 2nd digit)	0 Sensor 2 Input Disabled 1 Direct (no post processing) 2 Square Root of Sensor 2 Input 3 Inverse of Sensor 3 Input 4 Output Register 1 (smart module)* 5 Output Register 2 (smart module)* 6 Output Register 3 (smart module)* 7 Output Register 4 (smart module)*

*\*Note: The logic for sensor 2 is not the same as sensor 1, sensor 3, or sensor 4. The 1st and 3rd digits must both be set to 0. Selecting 040 to 070 in the 2nd digit of Code 4 directly selects one of the following settings in the smart register 1 map (3rd digit):*

2nd Digit	Output Register Map
4 selects	0 Averaged Signal 1
5 selects	1 Averaged Signal 2
6 selects	2 Averaged Signal 3
7 selects	3 Averaged Signal 4

- 17 If required enter Code 5 and select the required post processing settings for **sensor 3** in the 1st digit and the required register map setting in the 3rd digit.

**CH3** [Cod\_5] [X7X]

FIRST DIGIT	THIRD DIGIT
<b>SENSOR 3 INPUT POST PROCESSING</b>	<b>OUTPUT REGISTER MAP</b>
0 Direct Display of Input (no processing) 1 Square Root of Sensor 3 Input 2 Inverse of Sensor 3 Input 3 <b>Meters with 4 kB memory</b> NO Linearization <b>Meters with 32 kB memory</b> 32-point Linearization of Sensor 3 Input using Table 3 Note: All linearization tables are set up in the Calibration Mode [24X].	0 Averaged signal SENSOR 1 1 Averaged signal SENSOR 2 2 Averaged signal SENSOR 3 3 Averaged signal SENSOR 4 4 - 5 - 6 - 7 Smart input module register 1 code setup



Note the output register map is different for each smart input module type.

- 18 If required enter Code 6 and select the required post processing settings for **sensor 4** in the 1st digit and the required register map setting in the 3rd digit.

**CH4** [Cod\_6] [X7X]

FIRST DIGIT
<b>SENSOR 4 INPUT POST PROCESSING</b>
0 Direct Display of Input (no processing) 1 Square Root of Sensor 4 Input 2 Inverse of Sensor 4 Input 3 <b>Meters with 4 kB memory</b> NO Linearization <b>Meters with 32 kB memory</b> 32-point Linearization of Sensor 4 Input using Table 4 Note: All linearization tables are set up in the Calibration Mode [24X].

Press the **P** button to save the settings.

- 19 Press the **P** and **↑** buttons at the same time to return to the operational display.

## Example Setup Procedure

Our customer requires to monitor the weight in a grain silo and also control dispensing the grain (See Figure 8).

Texmate installed an ISS7/8 input module connected to the load cells via a terminal block. Load cell sensors 2, 3, and 4 are installed below the silo legs and are used to monitor the silo weight. They are 20 tonne sensors with a 20 mV/V sensor signal. Load cell sensor 1 is used to control grain dispensing and is a 100 kg sensor with a 2 mV/V sensor signal.

All four load cells are configured with a 10 Hz output rate. This is necessary to keep up with the rate the grain is emptied from the silo.

### 1 Select 50 Hz input line frequency, with a 10 Hz averaged output rate for all sensors. Select a 2 mV/V sensor input for sensor 1:

In **CODE 2** select **X77** then press **P** button.

Display toggles between **SM1** **000**

Set **SM1** to **213**

### 2 Select 20 mV/V voltage range for sensors 2, 3, and 4:

In **CODE 5** reset to **X77** then press **P** button.

Display toggles between **SM2** **000**

Set **SM2** to **333**

### 3 Select sensor 1 as the dispensing weight for CH1:

In **CODE 2** select **X70**

### 4 Select the silo sensor 2 load cell for CH2:

In **CODE 4** select **X50**

### 5 Select the silo sensor 3 load cell for CH3:

In **CODE 5** select **X72**

### 6 Select the silo leg sensor 4 load cell for CH4:

In **CODE 6** select **X73**




Figure 8 – Example 1: Monitoring Weight and Distribution

## Customer Configuration Settings:

	1st Digit	2nd Digit	3rd Digit
57761			
57762			
CH1 Cod_2		7	
CH2 Cod_4	0		0
CH3 Cod_5		7	
CH4 Cod_6		7	

### WARRANTY

Texmate warrants that its products are free from defects in material and workmanship under normal use and service for a period of one year from date of shipment. Texmate's obligations under this warranty are limited to replacement or repair, at its option, at its factory, of any of the products which shall, within the applicable period after shipment, be returned to Texmate's facility, transportation charges pre-paid, and which are, after examination, disclosed to the satisfaction of Texmate to be thus defective. The warranty shall not apply to any equipment which shall have been repaired or altered, except by Texmate, or which shall have been subjected to misuse, negligence, or accident. In no case shall Texmate's liability exceed the original purchase price. The aforementioned provisions do not extend the original warranty period of any product which has been either repaired or replaced by Texmate.

### USER'S RESPONSIBILITY

We are pleased to offer suggestions on the use of our various products either by way of printed matter or through direct contact with our sales/application engineering staff. However, since we have no control over the use of our products once they are shipped, NO WARRANTY WHETHER OF MERCHANTABILITY, FITNESS FOR PURPOSE, OR OTHERWISE is made beyond the repair, replacement, or refund of purchase price at the sole discretion of Texmate. Users shall determine the suitability of the product for the intended application before using, and the users assume all risk and liability whatsoever in connection therewith, regardless of any of our suggestions or statements as to application or construction. In no event shall Texmate's liability, in law or otherwise, be in excess of the purchase price of the product.

Texmate cannot assume responsibility for any circuitry described. No circuit patent or software licenses are implied. Texmate reserves the right to change circuitry, operating software, specifications, and prices without notice at any time.

# TEXMATE INC

1934 Kellogg Ave. • Carlsbad, CA 92008

Tel: 1-760-598-9899 • USA 1-800-839-6283 • That's 1-800-TEXMATE

Email: orders@texmate.com • Web: www.texmate.com

For product details visit [www.texmate.com](http://www.texmate.com)