



LYNX FAMILY

## FX-B101Q Lynx Bargraph Meter 101 Segment in a 9/64 DIN CASE

A low cost red or optional green, 101 segment bargraph in a 36x144 case, providing a direct connection to most sensors for monitoring and measurement applications.

### General Features

- External transmitters or signal conditioners can be eliminated by directly connecting the sensor to more than 33 **I-Series** Plug-in Input Signal Conditioning Modules that include:
  - AC Current
  - AC Voltage
  - DC Current
  - DC Voltage
  - Load Cell
  - Pressure
  - Process
  - Prototype
  - Resistance
  - Strain-gage
  - Temperature
  - 4 to 20 mA
- Pre-calibrated **I-Series** Input Signal Conditioning modules, that have span or zero potentiometers, can be interchanged between any **I-Series** compatible meter, without recalibration, because all of the analog scaling and reference circuitry is self-contained within the module. 5 or 10 V DC excitation is provided for resistance bridge type sensors.
- 24 V DC excitation is available to power external transmitters and 5 or 10 V DC excitation is available for strain-gages, load cells and resistance bridge type sensors.
- A red or optional green 101 segment bargraph.
- Auto-sensing AC/DC power supply. For voltages between **85-265 V AC / 95-300 V DC (PS1)** or 14-48 V AC / 10-72 V DC (PS2).
- Optional 16 Bit isolated analog output that can be used to drive an external process device such as a chart recorder, remote display, or for retransmission to a central control room. User or factory scalable to 4 to 20 mA, 0 to 20 mA or 0 to 10 V across any desired span from  $\pm$  one bar to the full scale range
- Center zero setting, header selectable.
- Provision for external brightness setting switch (by connecting the DIM to the GND pin on the back of the meter).
- Smart averaging (to speed up display response).
- Optional NEMA-4 front cover.
- UL Listed

### Input Module Compatibility

**LYNX FAMILY:** More than 33 different Plug-in **I-Series** Input Signal Conditioners are approved for Texmate's Lynx Family of meters. As shown on pages 10-12.



LYNX


See [www.texmate.com](http://www.texmate.com) for an up to date listing.

### Specifications

**Input Specs:**.....Depends on range and function selected  
**A/D Converter:**.....14 bit single slope  
**Accuracy:**..... $\pm(0.05\%$  of reading + 1 segment)  
**Temp. Coeff.:**.....100 ppm/ $^{\circ}$ C (Typical)  
**Warm up time:**.....2 minutes  
**Conversion Rate:**.....10 conversions per second (Typical)  
**Bargraph Display:**.....**101 segment 4" vertical (std),**  
 horizontal (optn), **red (std),** green (optn)  
**Polarity:**.....Selectable center zero  
**Positive Overage:**..Bargraph display flashes  
**Negative Overage:** First segment of bargraph display flashes  
**Analog Output:**.....Isolated 16 bit user scalable mA or V  
**OIC (mA out)**.....4-20 mA @ 0 to 500 $\Omega$  max loop resistance  
**OIV (volts out)**..... 0-10 V DC @ 500  $\Omega$  or higher resistance  
**Power Supply:**.....AC/DC Auto sensing wide range supply  
**PS1 (std)**.....**85-265 VAC, 50-400Hz / 95-300 VDC @ 1.5W**  
**PS2**..... 14-48 V AC, 50-400Hz / 10-72 V DC @1.5W  
**Operating Temp.:**.....0 to 50 $^{\circ}$ C  
**Storage Temp:**.....–20 $^{\circ}$ C to 70 $^{\circ}$ C  
**Relative Humidity:**....95% (non condensing)  
**Case Dimensions:** ....3/32 DIN, Bezel: 36x144 mm (1.42"x5.69")  
 Depth behind bezel: (4.64") 117.5 mm  
 Plus 10 mm (0.39") for Right-angled connector, or plus 18.3 mm (0.72") for Straight-thru connector, or plus 26.5 mm (1.05") for Push-On connector.  
**Weight:**.....9.5 oz., 12 oz when packed

### Index

Analog Output Scaling and Calibration . . . . . 7	Functional Diagram . . . . . 8	Input Signal Conditioning Modules . . . . . 10-12	Panel Adapter . . . . . 16
Case Dimensions . . . . . 17	General Features . . . . . 1	Installation Guideline . . . . . 12	Pin Descriptions . . . . . 8
Center Zero Mode Scaling For Bipolar Inputs . . . . . 6	Glossary of Programming Symbols & Modes of Operation . . . . . 2	One Point Quickset Rescaling and Calibration Procedure. . . . . 5	Reset Analog output Scaling and Calibration . . . . . 7
Component Layout . . . . . 9	Hinged Clear Lockable Poly NEMA 4X Splash Proof Cover . . . . . 17	Opening the Case to Access Mode Select Header. . . . . 4	Reset Scaling and Calibration . . . . . 5
Connector Pinouts . . . . . 8	Input Module Analog Calibration Procedures 15	Ordering Information . . . . . 18	Specifications . . . . . 1
Connectors . . . . . 9	Input Module Compatibility. . . . . 1	Overview of Display Modes, Scaling Capabilities & Operating Modes. . . . . 3	Two Point Quickset Scaling and Calibration . . . . . 3,5
Controls and Indicators . . . . . 2	Custom Face Plates & Scales . . . . . 13		



directly changed. The direction of change will be either up or down, as indicated by the UP and DOWN indicator LEDs. After the indicator LED lights up there is a 0.5 second delay before any change occurs. When a button is released and pressed down again the direction of change is reversed. As there are no menu or sub-menus to navigate, the programming and setup is quick and easy.

**Front Panel Buttons**

**Zero Button**

The Zero Button sets the low input signal scaling.

**Span Button**

The Span Button sets the high input signal scaling.

**Lo Button**

The Lo Button sets the analog output low setting.

**Hi Button**


The Hi Button sets the analog output high setting.

**Quickset Programming**


This bargraph features Texmate's unique QUICKSET PROGRAMMING. When a front panel button is pressed and held down, the associated function is

**Glossary of Programming Symbols and Modes of Operation**

To explain software programming procedures, logic diagrams are used to visually assist in following programming steps. The following symbols are used to represent the functions and displays of the meter:



**Standard or Center Zero Display Mode Select Header**



•Jumper clips enables standard display.




•Jumper clip to enable Center Zero display.



**Horizontal and Reverse Mounting**  
with Custom Face Plate Installed


**Horizontal or Reverse Mounting**

Meters can be mounted horizontally in the panel and for those applications that require an opposite growth of the bar, the meter can be vertically or horizontally mounted upside down



When two fingers are shown side by side, the two corresponding buttons must be pressed at the same time to initiate an indicated function.


## Over View of Display Modes, Scaling Capabilities and Operating Modes



### Standard Display Mode


#### Standard Scaling

Standard display mode selected and scaled so bar increases as input signal increases from Low to Hi.



#### Inverse Scaling


Standard display mode selected and scaled so the bar increases as the input signal decreases from Hi to Low.



### Center Zero Display Mode


#### Bipolar Center Zero

Center point display mode selected and scaled, so the bar increases upward from zero, for increasing positive inputs and downward from zero for increasing negative inputs. When the input is zero, only the center segment will be on.



#### Halfway Zero Point

Center point display mode selected and scaled, so the bar increases upwards or downwards from the center point, for signals that are greater or less than half the calibrated full scale range respectively. When the input is equal to half the full scale range, only the center segment will be on.



## Two Point Quickset Scaling and Calibration

Meters with **QUICKSET PROGRAMMING** feature a unique, easy-to-use, two point scaling and calibration system.

Scaling or calibration is accomplished simply, by applying a zero or low input signal and adjusting the bar to the desired reading, using the ZERO button. A higher input signal is then applied, and the bar is adjusted to the desired reading for that input value, using the SPAN button.


### IMPORTANT DETAILS THAT MAKE QUICKSET PROGRAMMING EASY TO USE AND UNDERSTAND

1. The zero and span buttons are functionally the same, except as follows: The ZERO button can initiate a scaling with input signals from zero to 95% of fullscale. The Span button can initiate a scaling with input signals from 5% of fullscale to 105% of fullscale.
2. When a Zero or Span button is pressed, the Up or Down indicator LED will immediately light up to show the direction, in which the Bar will move, after a 0.5 second delay. If the button is released and pressed again, the opposite Up or Down indicator will light up, and 0.5 seconds later the Bar will begin to move in that direction until the button is released. When the bar is being adjusted to zero or fullscale, the bar will automatically stop at the zero or fullscale position, and will not overshoot these positions, even if the button continues to be pressed.
3. While the bar is being adjusted, a new offset and scale factor is continuously being calculated. At the moment the button is released, and the scaling is accepted, the calculation data is memorized and implemented. The Scaling calculation is based on the new position of the Bar, the input signal being applied at that moment, and the previously memorized position of the Bar and the input signal that was being applied, when the other button was last released.
4. Positive and negative signals maybe integrated into a two point scaling. However when either a ZERO or SPAN button is pressed the input signal being applied, must be more than 5% higher or lower than the previously memorized value of the input signal, that was being applied when the other button was last released. If not, the bar will flash, the scaling will not be accepted, and the previous scaling will still be retained in memory.
5. Because of the requirement, that a new scaling input signal must be 5% higher or lower than the previously stored value, it can sometimes be difficult to implement a desired scaling, particularly when using a calibrator that only has fixed output values. In this case Reset the Scaling by pressing the ZERO and SPAN buttons simultaneously for two seconds. Both scaling memories will be erased and an internal default scale factor will be loaded. This provides a display of zero to fullscale on the bar for an input of approximately 0 to 100% of the range selected on the input signal conditioning module. After Resetting the Scaling a new calibration, using either button, can be implemented with new input signal values. It is good practice to always use the Zero button for lower input signals and the Span button for higher input signals, even when the bar display scale is inverted.
6. The larger the difference between two points used for calibration, the better the accuracy. However if the difference is too high, and the output from the input signal conditioning module is greater than +2.1VDC, or less than -1.05VDC, the bar will flash over range. The calibration will not then be accepted and, the previous scaling will still be retained in memory. In this case, either a lower input signal must be used, or a higher range on the input module should be selected to recalibrate the meter.

**Note:** Most input signal conditioners have provisions for analog calibration and scaling. If the meter's scale factor is set to read zero with a zero input (shorted input), and to read 10 Bars fullscale with a 2.000 V input, any pre-calibrated signal conditioner with an output that does not exceed - 1 V to + 2 V, will read correctly in the meter without any further calibration.


## Opening the Case to Access Mode Select Header

To remove front bezel lightly lever the plastic catches up and forward in the sequence shown by the numbers



To remove rear cover plate press down lightly to release two plastic catches, on either side of the case and lever backwards.

## Meter Exploded view



## Two Point Quickset Scaling and Calibration Procedure (continued)

**Note:** Calibrating the bargraph requires two input signals. Using the minimum input (LO Input) and maximum input (HI Input) signals are recommended for optimal accuracy.

However, scaling can be accomplished with any two signals that are higher or lower than each other by more than 5% of the full scale and are not greater than +2.1VDC or less than -1.05VDC.


See page 10-12 for information on input modules that may be used with this meter. Confirm that the correct range and input is selected on the input signal conditioning module.

### STEP A SET THE LOW INPUT SIGNAL READING ON THE BAR

- 1) Apply the LO input signal (4ma in this example) to the input pins.
- 2) Using the ZERO button adjust the bar down to the required position.


**Warning:** Do not press the Span button when a low signal is applied or the Zero button when a high signal is applied. Doing so will tamper with the calibration process and necessitate resetting and recalibrating the meter.

If erroneous signals or buttons are pressed, tampering with the calibration, please perform the "Reset Scaling and Calibration" procedure below, then repeat steps A and B.



### STEP B SET THE HIGH INPUT SIGNAL READING ON THE BAR


- 1) Apply the high input signal (20mA in this example) to the input pins. Using the SPAN button, adjust the bar to the required position. This position can be higher or lower than the position adjusted in Step 2. The scaling for a 4 to 20mA input is now complete.



## Reset Scaling and Calibration

### RESET THE SCALING

- 1) Apply power to the meter and press the ZERO and SPAN buttons simultaneously for 2 seconds. This erases any previously memorized scalings and resets the meter's scaling to the factory default. Factory default scaling is approximately zero to full scale for an input that is 0 to 100% of the range selected on the input signal conditioner.



## One Point Quickset Rescaling and Calibration Procedure


### ONE POINT RECALIBRATION

As explained earlier, the FX-B101Q bargraph is calibrated using two point calibration. Once a bargraph is calibrated, the low end of the range may be then recalibrated without affecting the calibration of the high end, and vice versa.

For example, take an FX-B101Q that has been calibrated to read zero to full scale for an input of 4 to 20mA. If now the scaling has to be changed to read zero to full scale for an input of 0 to 20mA, only the low (4 mA) end needs to be recalibrated. The high (20 mA) end of the scaling is left untouched, and so does not change. The following one point recalibration procedure is used for this purpose.

### STEP A RECALIBRATE THE LOW INPUT SIGNAL READING ON THE BAR

- 1) Apply the LO input signal (0ma in this example) to the input pins. The first segment will flash, indicating an under range condition.
- 2) Using the ZERO button adjust the bar up to the required position.
- 3) The FX-B101Q has now been recalibrated to read zero to full scale for a 0 to 20 mA input.



## Center Zero Mode Scaling For Bipolar Inputs

The procedure for scaling the bar graph for bipolar signals is very simple. If say CH1 has to be scaled for -1V to +1V, the steps are as follows:

### STEP A SELECT THE CENTER ZERO DISPLAY MODE FOR CH1

- 1) Following the instructions on page 4, remove the meter from the case.
- 2) Select the Center Zero Mode for CH1 by repositioning the jumper clip on the Center Zero Display Mode Select Header.

Center Zero  
Mode  
Selected



### STEP B REVIEW THE INPUT MODULE STATUS


- 1) See pages 10 – 12 for information on input modules that may be use with this meter.
- 2) Confirm that the correct range and input is selected on the input signal conditioning module.

**Note:** When undertaking an initial set up and primary scaling and calibration of the meter it is best to start with a reset of the scaling.

### STEP C RESET THE SCALING ON CHANNEL ONE

- 1) Apply power to the meter and press the ZERO and SPAN buttons simultaneously for 2 seconds. This erases any previously memorized scalings, and resets the scaling to the factory default, of approximately zero to full scale, for an input, that is 0 to 100% of the range selected on the input signal conditioner.


Reset the scaling to the default value on by pressing the Zero and Span buttons simultaneously for 2 secs.



### STEP D SET THE LOW INPUT SIGNAL READING ON THE BAR

- 1) Apply the LO input signal (-1V in this example) to the input pins.
- 2) Using the ZERO button adjust the bar down to the required position. In this case, all the bar segments from mid point down to the bottom will be ON.


Apply -1V to the Input Signal Pins and adjust bar display to the required position



### STEP E SET THE HIGH INPUT SIGNAL READING ON THE BAR

- 1) Apply the high input signal (+1V in this example) to the input pins.
- 2) Using the SPAN button adjust the bar to the required position. This position could be higher or lower than the position adjusted in Step 2. In this case, all the bar segments from mid point up to the top will be ON.
- 3) The scaling for an input of -1V to +1V is now complete.

Apply +1V to the Input Signal Pins and adjust bar display to the required position



## Analog Output Scaling and Calibration


When the optional analog output module is installed, an independently calibrated 16 bit isolated, voltage or current analog output is available. **The analog signal is independently scaled to the input signal and not to the bargraph display.** It is important to note that the Analog Output is completely independently of the bargraph display. This means for example that the bargraph display may be scaled to go from zero to full scale as the input changes from 0 to 5V, while at the same time, the analog output is scaled to go from 4 to 20mA as the input changes from 2 to 3V. Rescaling the bargraph or the analog output will not affect the scaling of the other.

To calibrate the Analog Output you must be able to input two input signals. Usually the minimum input (LO Input) and the maximum (HI Input) signals are used for maximum accuracy.

For example: the three steps to obtain an Analog Output of 4mA to 20mA for an input of 0 to 10V are:

### STEP A CALIBRATE ANALOG OUTPUT FOR LO SIGNAL

- 1) Apply the low input signal (0V in this example) to the meter.
- 2) Connect an external multimeter to the analog output pins (Pins 17 and 18).
- 3) Using the LO button adjust the analog output as measured on the external multimeter to be the required value. (4mA in this example). When the LO button is pressed, the UP or DOWN indicator LED shows the direction of change. To reverse the direction of change release the LO button and press down again. Initially the output changes very slowly, but speeds up as the LO button remains pressed down. The analog output for a low input can be set in this step to any value in the range of 0 to 20mA or 0 to 10V ( if the voltage output option is selected).




**Warning:** Do not press the Hi button when a low signal is applied or the Lo button when a high signal is applied. Doing so will tamper with the analog output calibration process and necessitate resetting and recalibrating the Analog Output.

If erroneous signals or buttons are pressed, tampering with the analog output calibration, please perform the "Reset Analog output Scaling and Calibration" procedure below, then repeat steps A and B.

### STEP B CALIBRATE ANALOG OUTPUT FOR HI SIGNAL

- 1) Next apply the high input signal (10V in this example) to the meter.
- 2) Using the HI button, adjust the analog output as measured on the external multimeter to be the required value. (20mA in this example). When the HI button is pressed the UP or DOWN indicator LED shows the direction of change. Release the HI button and press again to reverse the direction of change. Initially the output changes very slowly, but speeds up as the HI button continues to remain pressed. This output may be higher or lower than the value set in Step 2, and may be any value in the range of 0 to 20mA or 0 to 10V. This allows the easy reversal of analog output that is required in some applications.




## Reset Analog Output Scaling and Calibration


### RESET THE ANALOG OUTPUT SCALING

- 1) Press the LO and HI buttons simultaneously and hold them down for 2 seconds. This will reset the analog output scaling to the default value. The default analog output scaling is approximately 0 to 20mA (0 to 10V if voltage output option is selected) for an input that is 0 to 100% of the range selected on the input signal conditioner.

Reset the analog output scaling by pressing the LO and HI buttons simultaneously for 2 secs.




## Functional Diagram



## Connector Pinouts

This meter uses plug-in type screw terminal connectors for all input and output connections. The power supply connections (pins 23 and 24) have a unique plug and socket outline to prevent cross connection. The main board uses standard right-angled connectors. Replacement 2-, 3-, and 4-pin plug connectors are available.



### WARNING

AC and DC power supply voltages are hazardous. Make sure the power supply is isolated before connecting to the meter.

## Pin Descriptions

### Input Signal – Pins 1 to 6

Pins 1 to 6 are reserved for the input signal conditioner. See the data sheet for the selected input signal conditioner.

### Pins 17 to 21 – Rear Panel Switches

**Pin 17 ANALOG OUTPUT (+).** mA (0 to 20 mA/4 to 20 mA) or V (0 to 10 V) output is header selectable.

**Pin 18 ANALOG OUTPUT (-).** mA (0 to 20 mA/4 to 20 mA) or V (0 to 10 V) output is header selectable.

**Pin 19 Programming LOCK.** By connecting the LOCK pin to the COMMON pin, the meter's programmed parameters can be viewed but not changed.

**Pin 20 COMMON.** To activate the LOCK or DIM functions from the rear of the meter, the respective pins have to be connected to the COMMON pin. This pin is connected to the internal power supply ground.

**Pin 21 DIM.** By connecting the display dim (DIM) pin to the COMMON pin, the display brightness setting is halved.


### Pins 23 and 24 – AC/DC Power Input

Auto-sensing AC/DC power supply. For voltages between 85-265 V AC, 50~400Hz / 95-300 V DC (PS1) or optional 14-48 V AC 50~400Hz / 10-72 V DC 1.5W nominal. (PS2).

**Pin 23 AC Neutral / -DC.** Neutral power supply line.

**Pin 24 AC line / +DC.** Live power supply line.

### Internal Function Header Pin out




**Internal header pins 1, 2, 3, 6, and 7** are for factory settings only. Not for external use!

**4 HOLD.** By connecting the HOLD pin to the GND pin, the displayed reading is frozen, however, A/D conversions continue. When the HOLD pin is disconnected from the GND pin, the correct reading is displayed.

**5 GND.** This pin is connected to the internal power supply ground.



# Component Layout



# Connectors

Standard plug-in screw terminal blocks provided by Texmate:




## WARNING

AC and DC input signals and power supply voltages can be hazardous. Do Not connect live wires to terminal blocks, and do not insert, remove or handle terminal blocks with live wires connected.


**Input Power Screw Terminal Plug**

Part Number: 93-PLUG2P-DP




**Right-angled Screw Terminal Plug**

Part Numbers:  
 93-PLUG2P-DR...2 pins  
 93-PLUG3P-DR...3 pins  
 93-PLUG4P-DR...4 pins  
 93-PLUG5P-DR...5 pins  
 93-PLUG6P-DR...6 pins




**Straight-thru Input Power Screw Terminal Plug**

Part Number: 93-PLUG2P-SP



**Straight-thru Screw Terminal Plug**

Part Numbers:  
 93-PLUG2P-DS...2 pins  
 93-PLUG3P-DS...3 pins  
 93-PLUG4P-DS...4 pins



# I-Series Input Signal Conditioning Modules


Many additional input modules are available and others are constantly being developed. Check with your local distributor or [www.texmate.com](http://www.texmate.com) for updated information.

Precalibrated **I-Series** input modules, that have span or zero potentiometers, can be interchanged between any **I-Series** compatible meter, without recalibration, because all of the analog scaling and reference circuitry is self-contained within the module. Where appropriate, all the standard ranges shown are designed to be header selectable by the user, and Texmate's unique SPAN ADJUST Header facilitates scaling to almost any required engineering unit.


Unless otherwise specified Texmate will ship all modules precalibrated with factory preselected ranges and/or scalings as shown in **BOLD** type. Other precalibrated standard ranges or custom ranges may be ordered. Factory installed custom scaling and other custom options are also available (see Ordering Information, Special Options on last page).

Symbols Indicate Module Compatibility Within Meter Families		
TIGER Family	LEOPARD Family	LYNX Family
TIGER Family	LEOPARD Family	LYNX Family
TIGER Family	LEOPARD Family	LYNX Family
<b>ALL MODELS</b>	<b>SOME MODELS</b>	<b>MODEL SPECIFIC</b>

## IA03: AC Milliamps Scaled RMS, 2/20/200mA AC




## IA01: AC Volts Scaled RMS, 200/300V AC




## IA04: AC AC Amps Scaled RMS, 1 Amp AC


## IA05: AC AC Amps Scaled RMS, 5 Amp AC




## IA02: AC Volts Scaled RMS, 200mV/2V/20V AC




## IA06: AC Volts True RMS, 300V AC




## IA07: AC Volts True RMS, 200mV/2V/20V AC




## ID02: DC Millivolts, 20/50/100/200mV DC w/24V DC Exc



## IA08: AC Milliamps True RMS, 2/20/200mA AC




## ID03: DC Milliamps, 2/20/200mA DC w/24V DC Exc




# I-Series Input Signal Conditioning Modules Continued

**IA09:** AC Amps True RMS, 1 Amp AC


**IA11:** AC Amps True RMS, 5 Amp AC




**IA10:** AC Millivolts, Scaled RMS, 100mV AC



**IA12:** AC Millivolt RMS Sigma Delta




**ID01:** DC Volts, 2/20/200V/Custom w/24V DC Exc




**ID04:** DC Amps, 5A DC


**ID09:** DC Amps, 1A DC




**ID05:** DC Volts 2/20/200/Custom V DC with Offset and 24V Exc.




**ID07:** DC Milliamps, 2/20/200mA DC with Offset and 24V Exc



**IF02:** Line Frequency




**IGYZ:** Universal Direct Pressure (Absolute or Differential/Gage)  
See below for ordering code options




**IP01:** Process Loop, 4-20mA


**IP02:** Process Loop, 4-20mA with 24VDC EXC



**IP03:** Process Input, 1-5V DC with Offset, 24V Exc




**IP07:** Universal Process Input  
2V/5V/10V/20V/200V/2mA/20mA/Custom




# I-Series Input Signal Conditioning Modules Continued

**IR02:** 3 wire Potentiometer 1KΩ min (0-F.S.)




**IT06:** Thermocouple, J Type (0-1400 °F)

**IT08:** Thermocouple, J Type (0-760 °C)




**IR03:** Linear Potentiometer 1KΩ min




**IT07:** Thermocouple, K Type (0-1999 °F)

**IT09:** Thermocouple, K Type (0-1260 °C)



**IR04:** Resistance 2KΩ (Lynx only)

**IR05:** Resistance 2KΩ (Leopard only)



## Installation Guidelines

### Installation

1. Install and wire meter per local applicable codes/regulations, the particular application, and good installation practices.

2. Install meter in a location that does not exceed the maximum operating temperature and that provides good air circulation.

3. Separate input/output leads from power lines to protect the meter from external noise. Input/output leads should be routed as far away as possible from contactors, control relays, transformers and other noisy components. Shielding cables for input/output leads is recommended with shield connection to earth ground near the meter preferred.

4. A circuit breaker or disconnect switch is required to disconnect power to the meter. The breaker/switch should be in close proximity to the meter and marked as the disconnecting device for the meter or meter circuit. The circuit breaker or wall switch must be rated for the applied voltage (e.g., 120VAC or 240VAC) and current appropriate for the electrical application (e.g., 15A or 20A).

5. See *Case Dimensions* section for panel cutout information.


6. See *Connector Pinouts* section for wiring.

7. Use 28-12 AWG wiring, minimum 90°C (HH) temperature rating. Strip wire approximately 0.3 in. (7.8 mm).


8. Recommended torque on all terminal plug screws is 4.5 lb-in (0.51 N-m).



**IS05:** Pressure/Load Cell 20/2mV/V, 5/10V Exc 4-wire



**IS06:** Pressure/Load Cell Ext Exc., 20/2mV/V, 4-wire




**IT03:** RTD, 100Ω Pt. 2/3/4-wire (-200 to 800°C)

**IT04:** RTD, 100Ω Pt. 2/3/4-wire (-200 to 1470°F)

**IT05:** RTD, 100Ω Pt. 2/3/4-wire (-199.9 to 199.9°F)

**IT14:** RTD, 100Ω Pt. 2/3/4-wire (-199.9 to 199.9°C)



# Custom Face Plates and Scales

- Custom face plates have a non-recurring artwork charge. A serial number is then assigned to each artwork, to facilitate re-ordering. We prefer custom logos and special artwork to be supplied in an Illustrator or Photoshop file format.
- Small Run or One-Off custom face plates incur an installation charge, and are generally printed on a special plastic film, which is then laminated to custom faceplate blanks as required.
- Large Run (300 pieces min): custom face plates are production silk screened, issued a part number, and held in stock for free installation as required by customer orders.

Part Number Description

### Small Run Custom Face plates for Bargraphs


ART-NRC-DES	Small run NRC custom faceplate design
ART-FS1	Small run custom Faceplate - 1 color
ART-FS2	Small run custom Faceplate - 2 color
ART-FS3	Small run custom Faceplate - 3 color
ART-FS4	Small run custom Faceplate - 4 color
ART-FS5	Small run custom Faceplate - 5 color

Specify artwork serial number when ordering face plate installation.  
ie: AFB-XXXXX


### Large Run Custom Face plates for Bargraphs

ART-NRC-FILM	Large run NRC custom faceplate design & films
ART-FPMAINT	Inventory management fee for 2 years
ART-FL1	Large run 300pcs custom faceplate - 1 color
ART-FL2	Large run 300pcs custom faceplate - 2 color
ART-FL3	Large run 300pcs custom faceplate - 3 color
ART-FL4	Large run 300pcs custom faceplate - 4 color
ART-FL5	Large run 300pcs custom faceplate - 5 color

When ordering Large Run Face plates to be installed specify the custom part number issued for each different artwork. ie: 77-FLXXXXX




	1	1.2	1.5	2	2.5	3	4	4.5	5	6	7.5	8	9
	10	12	15	20	25	30	40	45	50	60	75	80	90
	100	120	150	200	250	300	400	450	500	600	750	800	900
	1000	1200	1500	2000	2500	3000	4000	4500	5000	6000	7500	8000	9000
10	12	15	20	25	30	40	45	50	60	75	80	90	
9						35	40	45		70		80	
8	10	12		20	25	30	35	40	50	60		70	
7			15								60		70
6	8			20	25	30	35	40	50	60			
5		9		15							50		60
4	6		10									50	
3											40		50
2	4	6		10								40	
1											30		40
0	2	3		5	5	5	5	5	5	5	5	5	5
	0	0	0	0	0	0	0	0	0	0	0	0	0
	10x5	6x2x2	5x3x2	4x5x2	5x5x2	6x5	8x5	9x5	10x5	6x5	7.5x5	8x5	9x5
	Div. 50	24	30	40	50	30	40	45	50	30	37.5	40	45



Some horizontal scales only have numbers on each second major division.


Face plate scales and numbers are shown close to their actual size.

**Dual input modules, and those modules exclusively compatible with the Leopard or Tiger Families, do not have zero and span adjustments. These modules are scaled and calibrated using the internal software functions of each individual meter.**




### Input and Output Pins

On most modules Pin 1 is the Signal High input and Pin 3 is the Signal Low input. Typically Pin 2 is used for Excitation Voltage output.



### Function Select Headers

On some modules various functions such as Amps and Volts, 4 wire and 6 wire, or cold junction compensation are selected by header positions that are marked on the PCB.




### 24 V DC Output for 4-20 mA Header

On some modules this header enables a 24 V DC 25 mA (max) Excitation/Auxiliary output to be connected to Pin 2 that can power most 4-20 mA process loop sensors.



### Excitation Output Select Headers

When excitation outputs are provided, they are typically 5 V DC max 30 mA, 10 V DC max 30 mA (300Ω or higher resistance) or external supply. They are selected by either a single or multiple jumper clip.






### INPUT RANGE Headers

Range values are marked on the PCB. Typically two to eight positions are provided, which are selected with either a single or multiple jumper clip. When provided, a custom range position is only functional when the option has been factory installed.




### ZERO Potentiometer (Pot)

If provided, the ZERO pot is always to the left of the SPAN pot (as viewed from the rear of the meter). Typically it enables the input signal to be offset  $\pm 5\%$  of the full scale display span.



### SPAN Potentiometer (Pot)



If provided, the 15 turn SPAN pot is always on the right side (as viewed from the rear of the meter). Typical adjustment is 20% of the input signal range.



### SPAN ADJUST Header



This unique five-position header expands the adjustment range of the SPAN pot into five equal 20% steps, across 100% of the input Signal Span. Any input Signal Span can then be precisely scaled down to provide any required Display span from full scale to the smallest viewable unit.

SPAN Adjust Header position	1	2	3	4	5
SPAN Pot %	20%	20%	20%	20%	20%
Signal Span %	20%	40%	60%	80%	100%



### ZERO OFFSET RANGE Header



When provided, this three position header increases the ZERO pot's capability to offset the input signal, by  $\pm 25\%$  of the full scale display span. For example a Negative offset enables a 1 to 5 V input to display 0 to full scale. The user can select negative offset, positive offset, or no offset (ZERO pot disabled for two step non-interactive span and offset calibration).



### SPAN RANGE Header

When this header is provided it works in conjunction with the SPAN ADJUST Header by splitting its adjustment range into a Hi and a Lo range. This has the effect of dividing the adjustment range of the SPAN pot into ten equal 10% steps across 100% of the input Signal Span.

SPAN Adjust Header position	Span Adjust Header					Span Range Header				
	1	2	3	4	5	1	2	3	4	5
SPAN Pot %	10%	10%	10%	10%	10%	10%	10%	10%	10%	10%
Signal Span %	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%



### ZERO ADJUST Header

When this header is provided, it works in conjunction with the ZERO OFFSET RANGE Header, and expands the ZERO pot's offset capability into five equal negative steps or five equal positive steps. This enables virtually any degree of input signal offset required to display any desired engineering unit of measure.

ZERO Adjust Header Position	Zero Adjust Header NEGATIVE OFFSET					Zero Adjust Header POSITIVE OFFSET				
	5	4	3	2	1	1	2	3	4	5
ZERO Pot Span	6400	6400	6400	6400	6400	6400	6400	6400	6400	6400
Offset Range	-25200 to -31600	-18900 to -25300	-12600 to -19000	-6300 to -12700	0 to -6400	0 to +6400	+12600 to +19000	+18900 to +25300	+25200 to +31600	

CALIBRATE position, Zero Pot disengaged (no offset applied)

### Tiger, Leopard and Q-Series Lynx meters have software calibration and scaling functions that can expand or be used in conjunction with the analog capabilities of any compatible modules.

**Note:** I-Series modules with analog calibration and scaling capability can be interchanged between any compatible meter without recalibration. However, meters that also have software scaling and calibration capabilities such as meters in the Leopard and Tiger families or Lynx Q-Series (Quickset programming), must have their software scaling set to unity gain.

#### Basic standard range calibration of direct reading modules that utilize either Auto Zero or a ZERO pot, an INPUT RANGE Header and or a SPAN pot.

- 1 If the module has an INPUT RANGE Header, reposition the jumper clip to select the desired input signal range.
2. Apply a zero input or short the input pins. The display will auto zero, or if the module has a ZERO pot, it should be adjusted until the display reads zero.
- 3 Apply a known input signal that is at least 20% of the full scale input range and adjust the SPAN pot until the display reads the exact input value. The Lynx family of Q meters can accept negative signals also, and may be scaled for inputs from -50% to +100% of the range selected on the input signal conditioning module.

#### Wide range scaling, in engineering units not requiring offsets, with modules that utilize auto-zero or a ZERO pot, a SPAN RANGE Header and or a SPAN ADJUST Header.

Texmate's unique SPAN ADJUST and SPAN RANGE Headers provide the circuit equivalent of an ultra-precision one megohm 75 or 150 turn potentiometer that can infinitely scale down any Input Signal SPAN to provide any Display Span from full scale to the smallest viewable unit.

If the module has an INPUT RANGE Header, and the required full scale Display Span (digital counts or bargraph segments) is to be larger than the directly measured value of the input Signal Span, then the next lower range on the INPUT RANGE Header should be selected. The resulting over range Signal Span is then scaled down, by selecting the position of the SPAN RANGE Header and or the SPAN ADJUST Header, which will reduce the input Signal Span to a percentage, that the required Display Span can be reached by calibration with the SPAN pot.

**Example A:** Using a FX-B101Q bargraph meter

Input signal 0 to 10 V to read zero to full scale.

Signal Span = 10 V, Display Span = 100 segments

- 1 Select the 2 V INPUT RANGE Header position. The standard direct scaling will provide a display of 100 segments with an input of only 2 V which is  $(2 \div 10) = 20\%$  of the examples 10 V Signal Span.
- 2 To scale down the Signal Span to 20% select the 20% Signal Span position on the SPAN ADJUST Header (position 1) or if the module has a SPAN RANGE Header, select (LO Range) and 20% Signal Span position on the SPAN ADJUST Header (position 2).
- 3 Apply a zero input or short the input pins. The display will auto zero, or if the module has a ZERO pot, it should be adjusted until the display reads zero.
- 4 Apply 10 V and adjust the SPAN pot until the display reads full scale.

#### Large offset scaling and calibration of process signal inputs with modules that utilize ZERO ADJUST Headers and or ZERO OFFSET RANGE Headers.

Texmate's unique ZERO OFFSET RANGE Header enables the use of a simple two step scaling and calibration procedure for those process signals that require large offsets. This eliminates the back and forth interaction, between zero and span settings, that is often required to calibrate less finely engineered products.

The first step is to set the ZERO OFFSET RANGE Header to the center position (No Offset) and scale down the Input Signal Span to a percentage that will enable calibration with the SPAN pot to reach the required Display Span.

The second step is to set the ZERO ADJUST and or ZERO OFFSET RANGE Header to provide a positive or negative offset so that calibration with the ZERO pot will offset the Display Span to produce the required display reading.

**Example B:** Using a FX-B101Q Bargraph meter.

Input signal 1 to 5 V to read zero to full scale.

Signal Span = 4 V, Display Span = 100 segments

- 1 If the module has an INPUT RANGE Header the 2 V position should be selected. This will provide a display of 101 segments for an input of 2 V which is  $(2 \div 4) = 50\%$  of the examples 4 V signal span. To scale down the Signal Span to 50% select the next higher 60% Signal Span position on the SPAN ADJUST Header (position 3).
- 2 If the module is a Process Input 1-5 V DC type, select the (Hi Range) position on the SPAN RANGE Header and the 100% Signal Span position on the SPAN ADJUST Header (position 5, max increase). This will provide a display of 101 segments for an input of 4 V which is 100% of the examples 4 V Signal Span.
- 3 Set the ZERO OFFSET RANGE Header to the center position (no offset). Apply 1 V and adjust the SPAN pot until the display reads 25 segments. A 4 V input would then read 100 segments.
- 4 Set the ZERO OFFSET RANGE Header to the negative offset position. If the module has a ZERO ADJUST Header select the position that will provide a negative offset of  $\approx 25$  segments. Apply 1 V and adjust the ZERO pot until the display reads zero. Apply 5 V and check that the display reads full scale.

**Example C:** Using a FX-B101Q Bargraph meter



Input signal 4 to 20 mA to read zero to full scale

Signal Span = 16 mA, Display Span = 100 segments

- 1 The full scale Signal Span of the Process Input 4-20 mA modules is 0 to 20 mA for a full scale Display Span of 0 to 100 segments.
- 2 Select the (Lo Range) Position on the Span Range Header and the 70% Signal Span position on the SPAN ADJUST Header (position 2).
- 3 Set the ZERO OFFSET RANGE Header to the center position (no offset). Apply 4 mA and adjust the SPAN pot until the display reads 25 segments. A 16 mA input would then read 100 segments.
- 4 Set the ZERO OFFSET RANGE Header to the positive offset position. If the module has a ZERO ADJUST Header select the position that will provide a negative offset of  $\approx -25$  segments. Apply 4 mA and adjust the ZERO pot until the display reads zero. Apply 20 mA and check that the display reads full scale.

**Fits 6" Edgewise Pointer Meter Cut-Outs**

The adapter snaps on the 36x144 mm (1.42"x5.69") case and enables single unit or stack mounting in an existing 6" edgewise pointer meter cut-out.




**Fits existing cut-outs for 6" (150 mm) edgewise switchboard pointer meters from:**

- Crompton
- G.E.
- Westinghouse
- Yokogawa
- and most others

Width: 43.7 mm to 48 mm (1.72" to 1.89")  
 Height: 143.4 mm to 149 mm (5.62" to 5.88")

Two bezel trim strips are provided with each adapter to finish off the edge of each individually mounted meter or the edge of each stack mounted array.


**Panel Adapter**  
**Part #: OP-PA/144X36**



Texmate's panel adapter enables modern DIN meters to fit in existing cutouts individually or stacked when replacing old 6" edgewise mechanical pointer meters.



## Case Dimensions



## Hinged Clear Lockable Polycarbonate NEMA 4X Splash Proof Cover


This rugged, impact resistant, clear lens cover is designed to be dust and water proof to NEMA 4 and IP65 standards. The lens cover consists of a base and cover with a cam hinge and key-lock locking device.

An O-ring, or neoprene gasket forms a seal between the base and the panel. When opened, a cam hinge prevents the cover from closing until pushed closed.


The cover has a tapered recess that, when closed, forms a capillary seal with a tapered ridge on the base. A capillary seal is created when capillary action causes a small amount of water to be drawn in between the two surfaces producing a water tight film around the sealing area.

For those applications, such as food processing, where fluid residues are unacceptable, apply a light coating of clear silicone grease, or other approved sealant to the mating groove to prevent any ingress of liquid and enable the cover to withstand steam cleaning.

Turning the key-lock tightens the cover to the base, ensuring seal integrity. A safety catch keeps the cover closed even when the key is turned to the open position and removed. The keyhole can also be used to attach a safety seal clip, preventing unauthorized opening.



# Ordering Information



Add to the basic model number the order code suffix for each standard option required. The last suffix is to indicate how many different special options and or accessories that you may require to be included with this product.

**Ordering Example: FX-B101Q-VR-PS1-IA01-OA2, the 2 OA's are, CR-CHANGE and a OP-PA/144X36**

► **BASE MODEL NUMBER**

FX-B101Q . . . 144x36mm, Lynx, 101 Segment Bargraph . . . . .

**Standard Options for this Model Number**

Order Code Suffix	Description	List
-------------------	-------------	------

► **DISPLAY**

VR . . . 101 Segment Red LED Bargraph, Vertical . . . . .  
 HR . . . 101 Segment Red LED Bargraph, Horizontal . . . . .  
 VG . . . 101 Segment Green LED Bargraph, Vertical . . . . .  
 HG . . . 101 Segment Green LED Bargraph, Horizontal . . . . .

► **POWER SUPPLY**

PS1 . . . 85-265VAC/95-300VDC . . . . .  
 PS2 . . . 15-48VAC/10-72VDC . . . . .

► **INPUT MODULES (Partial List. See www.texmate.com)**

Unless otherwise specified Texmate will ship all modules precalibrated with factory preselected ranges and/or scalings as shown in **BOLD** type.

IA01 . . AC-Volts Scaled RMS, 200/**300 AC** . . . . .  
 IA02 . . AC-Volts Scaled RMS, 200mV/**2V/20V AC** . . . . .  
 IA03 . . AC-mA Scaled RMS, 2/**20/200mA AC** . . . . .  
 IA04 . . AC-Amps Scaled RMS, **0-1 Amp AC (0-100.00)** . . . . .  
 IA05 . . AC-Amps Scaled RMS, **0-5 Amp AC (0-100.00)** . . . . .  
 IA06 . . AC-Volts True RMS, 200/**300V AC** . . . . .  
 IA07 . . AC-Volts True RMS, 200mV/**2V/20V AC** . . . . .  
 IA08 . . AC-mA True RMS, 2/**20/200mA AC** . . . . .  
 IA09 . . AC-Amps True RMS, **0-1 Amp AC (0-100.00)** . . . . .  
 IA10 . . AC-Millivolt, Scaled RMS, **100mV AC** . . . . .  
 IA11 . . AC-Amps True RMS, **0-5 Amp AC (0-100.00)** . . . . .  
 IA12 . . AC-Millivolt, True RMS, **100mV AC** . . . . .  
 ID01 . . DC-Volts, **2/20/200V**/Custom w/24V DC Exc. . . . .  
 ID02 . . DC-Millivolt, 20/50/**100/200mV DC** w/24V DC Exc . . . . .  
 ID03 . . DC-Milliamp, 2/**20/200mA DC** w/24V DC Exc . . . . .  
 ID04 . . DC-Amps, **5A DC** . . . . .  
 ID05 . . DC-Volts **2/20/200/Custom V DC** w/Offset and 24V Exc. . . . .  
 ID07 . . DC-Milliamp, 2/**20/200mA DC** w/Offset and 24V Exc. . . . .  
 ID09 . . DC-Amps, **1A DC** . . . . .  
 IF02 . . Line Frequency, 50-500VAC, 199.9Hz, or optional 400Hz . . . . .  
 IGYZ . . Universal Direct Pressure . . . . .  
 IP01 . . Process Loop, **4-20mA(0-100.00)** . . . . .  
 IP02 . . Process Loop, **4-20mA(0-100.00)** w/24VDC Exc . . . . .  
 IP03 . . Process Input, **1-5V DC(0-100.00)** w/Offset, 24V Exc. . . . .  
 IP07 . . Universal Process 2V/5V/**10V/20V/200V/2mA/20mA/Custom** . . . . .  
 IPT1 . . Prototype Board for Custom Design. . . . .  
 IR02 . . 3-Wire Potentiometer 1KΩ min (0-F.S.) . . . . .  
 IR03 . . Linear Potentiometer, 3-wire, 1KΩ min . . . . .  
 IR04 . . Resistance 2KΩ . . . . .

IS05 . . Pressure/Load Cell 20/**2mV/V**, 5/**10V** Exc 4-wire. . . . .  
 IS06 . . Pressure/Load Cell Ext Exc., 20/**2mV/V**, 4-wire . . . . .  
 IT03 . . RTD, 100Ω Pt. 2/**3/4-wire (-200 to 800°C)** . . . . .  
 IT04 . . RTD, 100Ω Pt. 2/**3/4-wire (-200 to 1470°F)** . . . . .  
 IT05 . . RTD, 100Ω Pt. 2/**3/4-wire (-190.0 to 199.0°F)** . . . . .  
 IT06 . . Thermocouple, J Type (**0-1400 °F**) . . . . .  
 IT07 . . Thermocouple, K Type (**0-1999°F**) . . . . .  
 IT08 . . Thermocouple, J Type (**0-760 °C**) . . . . .  
 IT09 . . Thermocouple, K Type (**0-1260°C**) . . . . .  
 IT14 . . RTD, 100Ω Pt. 2-, 3-, or 4-wire (-199.0 to 199.0°C). . . . .

► **ANALOG OUTPUT**

OIC . . . Isolated 16 Bit Current Output, 4-20mA . . . . .  
 OIV . . . Isolated 16 Bit Voltage Output, 0-10VDC . . . . .

**Special Options and Accessories**

Part Number	Description	List
-------------	-------------	------

► **SPECIAL OPTIONS (Specify Inputs or Outputs & Req. Reading)**

ZR . . . . . Calibrated Range Change to another Standard Range . . . . .  
 ZS-AOB . . . . . Custom scaling of analog output for Q-series bargraphs. . . . .

► **ACCESSORIES (Specify Serial # for Custom Artwork Installation)**

75-DMC14436B . . Side Slide Brackets-Wide opening (2 pc) . . . . .  
 75-DMC144X36 . . Side Slide Brackets-stand. (2 pc) - extra set . . . . .  
 93-PLUG2P-DP . . Extra Screw Terminal Conn., 2 Pin Power Plug . . . . .  
 93-PLUG2P-DR . . Extra Screw Terminal Conn., 2 Pin Plug . . . . .  
 93-PLUG3P-DR . . Extra Screw Terminal Conn., 3 Pin Plug . . . . .  
 93-PLUG4P-DR . . Extra Screw Terminal Conn., 4 Pin Plug . . . . .  
 93-PLUG5P-DR . . Extra Screw Terminal Conn., 5 Pin Plug . . . . .  
 DN.CAS144X36 . . Complete 144x36mm Case with Bezel . . . . .  
 75-DBZ144X36 . . Black Bezel for 144x36mm Case . . . . .  
 OP-MTL144x36 . . Metal Surround Case, includes screw mounting clips. . . . .  
 OP-MTLCLIP . . . . . Screw Mounting Clips (2 pc) - to screw tighten slide brackets . . . . .  
 OP-N4/144X36 . . 144x36mm clear lockable front cover-NEMA 4X, splash proof. . . . .  
 OP-PA/144X36 . . . . . Panel Adapter for 144x36mm from 6 inch cutout . . . . .

For Custom Face Plates and Scales see page 13.

Prices subject to change without notice.

**WARRANTY**

Texmate warrants that its products are free from defects in material and workmanship under normal use and service for a period of one year from date of shipment. Texmate's obligations under this warranty are limited to replacement or repair, at its option, at its factory, of any of the products which shall, within the applicable period after shipment, be returned to Texmate's facility, transportation charges pre-paid, and which are, after examination, disclosed to the satisfaction of Texmate to be thus defective. The warranty shall not apply to any equipment which shall have been repaired or altered, except by Texmate, or which shall have been subjected to misuse, negligence, or accident. In no case shall Texmate's liability exceed the original purchase price. The aforementioned provisions do not extend the original warranty period of any product which has been either repaired or replaced by Texmate.

**USER'S RESPONSIBILITY**

We are pleased to offer suggestions on the use of our various products either by way of printed matter or through direct contact with our sales/application engineering staff. However, since we have no control over the use of our products once they are shipped, **NO WARRANTY WHETHER OF MERCHANTABILITY, FITNESS FOR PURPOSE, OR OTHERWISE** is made beyond the repair, replacement, or refund of purchase price at the sole discretion of Texmate. Users shall determine the suitability of the product for the intended application before using, and the users assume all risk and liability whatsoever in connection therewith, regardless of any of our suggestions or statements as to application or construction. In no event shall Texmate's liability, in law or otherwise, be in excess of the purchase price of the product.

Texmate cannot assume responsibility for any circuitry described. No circuit patent or software licenses are implied. Texmate reserves the right to change circuitry, operating software, specifications, and prices without notice at any time.



1934 Kellogg Ave., Carlsbad, CA 92008  
 Tel: 1-760-598-9899 • 1-800-TEXMATE  
 Fax: 1-760-598-9828 • Email: orders@texmate.com

**FX-B01Q Technical Manual Copyright © 2020 Texmate Inc. All rights reserved. Published by: Texmate Inc. USA. Information in this Technical Manual is subject to change without notice due to correction or enhancement. The information described in this manual is proprietary to Texmate, Inc. and may not be copied, reproduced or transmitted, in whole or in part, in connection with the design, manufacture, or sale of apparatus, device or private label product without the express written consent of Texmate, Inc.**