A bakery customer has two tanks containing a release agent that is sprayed into the baking trays. If the release agent runs out, the bread sticks to the trays. Two release agent drums, TANK 1 and TANK 2 are placed onto two independent load-cell platforms and both load cell outputs are connected to a dual load-cell input module installed in a DI-60AT controller.

- 1. On start up, TANK 1 valve is open.
- When TANK 1 low level (set-point 1) operates, TANK 1 valve closes and TANK 2 valve opens.
- 3. The system is now operating from TANK 2.
- 4. TANK 1 is replaced, TANK 1 low level alarm is now OFF.
- When TANK 2 low level alarm operates, TANK 2 valve is closed and TANK 1 valve is opened.
- 6. The sequence is repeated.

The controller is programmed to scroll a text message across the display to indicate the tank in use, and when the tank low alarms are energized. For example:

- 1. If both tanks above their low setpoint then display = ["tANk 1"]
- 2. If TANK 1 is below low setpoint controller will automatically open TANK 2 valve and close TANK 1 valve, the scrolling display then = ["tANk 2 in use tANK 1 low"]

3. If TANK 1 is replaced therefore no low


alarms display then = ["tANk2"]

4. If TANK 2 is low, the controller will
automatically open TANK 1 valve and close
TANK 2 valve the display will then scroll

["tANK 1 in use tANK 2 low"]

5. If TANK 2 is replaced therefore no alarms display = ["tANk1"]

If both tanks are low the display will scroll ["tANk1 Lo tANk2 Lo"]



TANK LEVEL ANNUNCIATOR TANK 2 TANK 1 Release Release Agent Agent REGISTER RESETS П Shuttle Valve **TOTALIZERS** \$ CALCULATIONS LOAD CELL LOAD CELL SEQUENCE Spray Pump SSAGE YOUR Controller MESSAGING INPUTS STATUS To view TANK 1 Push UP button To view TANK 2 Push DOWN button

TANK LEVEL MACRO

The example macro has been written to

- 1. Automate the valve position and therefore the tank in use.
- 2.Scroll across the display appropriate text message indicating the condition of the tanks and valves.

Suggested Ordering Code Options for This Application

Basic Order Codes Comments

DI-60AT-DR-PS1-ISS5-OR12

Alphanumiric scrolling message. Up to see Tank1, Down to see Tank2

Note: Custom Smart App required. Charges vary depending on application. Contact Texmate.

Convever

LOAD-CELL