


16-BIT SMART DUAL LOAD CELL MODULE

16-BIT SMART DUAL LOAD CELL



The revolution in intelligent load cell controllers continues with our dual input module.

This powerful input module defines the next generation of intelligent load cell controllers, encapsulating high performance and precision measurement with dual input functionality.

When combined with the Tiger 320 Series operating system, the operator has all the solutions to weighing, bagging and continuous batching control applications. All these features plus the bonus of dual load cell inputs make this module the obvious choice over dated weighing controllers, PLC and timer technology.

Input Module
Order Code Suffix

ISS5 (50 Hz Rejection)

ISS6 (60 Hz Rejection)



Hardware Module Specifications	
Excitation	5 V DC, 130 mA maximum.
Input Range	Software selectable for sensors from 1 mV/V to 20 mV/V.
Input Channels	Dual, independent gains. Zero X-talk between channels each having 19-bit effective resolution.
Input Sensitivity	0.08 μV/Count maximum.
Zero Drift	± 40 nV/ °C typical.
Span Drift	± 200 ppm/ ° C of full scale maximum.
Non-linearity	± 0.003% of full scale maximum.
Input Noise	160 nVp-p typical at 1 Hz output rate.
Signal Processing Rate	20 Hz maximum, 1 Hz minimum.
Frequency Select	50/60 Hz noise rejection.

Software Module Features	
Output Rates	A choice of average response outputs, 1-20 Hz.
Gain Select	Choice of industry standards, 1-20 mV/V.
Frequency Select	50/60 Hz noise rejection.

Some Relevant Tiger 320 Series Operating System Features	
	Auto Zero Maintenance.
	Set TARE, Reset TARE.
	Setpoint Timer Functions.
	Setpoint Register Reset and Trigger Functions.
	On-demand Calibration.
	Macro Compiler for PLC Functions.
	32-Point Linearization.
	Totalizator and Serial Printing.

INPUTS	
★	Smart Dual Channel Precision


	Dual Channel Load-cell Pressure
--	---------------------------------

Smart Setup Registers

The meter uses three smart setup registers to configure smart input modules. ISS5 and ISS6 require **smart registers 1 and 2** to be set up. Because this is a dual input module, independent sensor inputs can be software selected for channels 1, 2, 3, and 4.

Sensor 1 and/or sensor 2 can be transferred to Channel 1 via Code 2, to Channel 2 via Code 4, to Channel 3 via Code 5, and to Channel 4 via Code 6.

Connector Pinouts



4-wire Bridge Configuration Dual Load Cell
(for 6-wire bridge connect sense leads and swop header)

Programming Procedures

1 Press the **P** and **↑** buttons at the same time to enter the main programming mode.

2 Press the **P** button three times to enter Code 2. Set Code 2 to [X77].

Cod_2 [X77]

This setting enters the **smart register 1** code setup menu.

FIRST DIGIT
TIGER PROCESSING RATE
0 10 Hz
1 10 Hz
2 100 Hz
3 100 Hz

SECOND DIGIT
MEASUREMENT TASK
0 Voltage, Current
1 TC (3rd digit selects type of TC)
2 RTD 3-wire (3rd digit selects type of RTD)
3 RTD 2- or 4-wire (3rd digit selects type of RTD)
4 Frequency
5 Period
6 Counter
7 Smart Input Module

THIRD DIGIT
OUTPUT REGISTER MAP
0 Averaged signal SENSOR 1
1 Averaged signal SENSOR 2
2 -
3 -
4 -
5 -
6 -
7 Smart input module register 1 code setup



Note the output register map is different for each smart input module.

3 Press the **P** button.

577E1 [000]

This menu provides settings unique to **smart register 1** of input module ISS5.

FIRST DIGIT
LINE FREQUENCY
0 60 Hz rejection
1 -
2 50 Hz rejection
3 -

SECOND DIGIT
SENSOR 1 INPUT mV/V (5 V Exc.)
0 1 mV/V
1 2 mV/V
2 3 mV/V
3 20 mV/V
4 -
5 -
6 -
7 -

THIRD DIGIT
OUTPUT RATE
0 1 Hz averaged
1 5 Hz averaged
2 10 Hz averaged
3 20 Hz averaged
4 -
5 -
6 -
7 -

4 Using the **↑**/**↓** buttons, select the relevant **line frequency** rejection, **sensor 1** input, and the **output rate** common to both sensor inputs.

5 Press the **P** button. The display returns to [Cod_2] [X77].

Cod_2 [X77]

6 Using the **↓** button, reset the 3rd digit to zero [X70] to leave the smart register 1 menu.

Note, leaving the 3rd digit as 7 means the display constantly cycles between [Cod_2] and [SMt1].

7 Press the **P** button 3 times to enter Code 5. Set Code 5 to [X77].

Cod_5 [X77]

FIRST DIGIT
CH3 POST PROCESSING
0 Direct Display of Input (no processing)
1 Square Root of Channel 3
2 Inverse of Channel 3
3 4 kB Meters NO Linearization
32 kB Meters 32-point Linearization of CH3 using Table 3
<i>Note:</i> All linearization tables are set up in the Calibration Mode [24X].

SECOND DIGIT
MEASUREMENT TASK
0 No Function
1 Voltage, current
2 TC (3rd digit selects type of TC)
3 RTD (3rd digit selects type of RTD)
4 Real Time Clock & Timer (3rd digit selects type)
5 -
6 -
7 Smart Input Module

THIRD DIGIT
OUTPUT REGISTER MAP
0 Averaged signal SENSOR 1
1 Averaged signal SENSOR 2
2 -
3 -
4 -
5 -
6 -
7 Smart input module register 2 code setup



Note the output register map is different for each smart input module.

8 Press the **P** button.

This setting enters the **smart register 2** code setup menu.

5P7E2 000

FIRST DIGIT
Not relevant

SECOND DIGIT
Not relevant

THIRD DIGIT
SENSOR 2 INPUT mV/V (5 V Exc.)
0 1 mV/V
1 2 mV/V
2 3 mV/V
3 20 mV/V
4 -
5 -
6 -
7 -

This menu provides settings unique to **smart register 2** of the ISS5 and ISS6 input module.

9 Using the **↑**/**↓** buttons, select the **sensor 2 input** from the 3rd digit.

10 Press the **P** button to save the settings.

The display toggles between [Cod_5] and [X77]. Cod_5 X77

11 Using the **↓** button, reset the 3rd digit to 0 to leave the smart register 2 menu.

12 Press the **P** and **↑** button at the same time to return to the operational display.

Select a Channel Select the output register for the required channels

13 Press the **P** and **↑** button at the same time again to re-enter the main programming mode.

14 Press the **P** button three times to enter Code 2.

15 Set Code 2 to [X7X]. Select the required processing rate for **CH1** in the 1st digit and the required register map settings (sensor 1 or sensor 2) in the 3rd digit.

CH1 Cod_2 X7X

FIRST DIGIT
TIGER PROCESSING RATE
0 10 Hz
1 10 Hz
2 100 Hz
3 100Hz



Note the output register map is different for each smart input module type.

THIRD DIGIT
OUTPUT REGISTER MAP
0 Averaged signal SENSOR 1
1 Averaged signal SENSOR 2
2 -
3 -
4 -
5 -
6 -
7 Smart input module register 1 code setup

16 If required enter Code 4 and select the required register map settings for **CH2** in the 2nd digit.

CH2 Cod_4 0X0

FIRST DIGIT
MEASUREMENT TASK
0 Voltage, Current
1 TC (type as per 2nd digit)
2 RTD (type as per 2nd digit)
3 Second Digital Input Channel (type as per 2nd digit)

SECOND DIGIT	
FOR VOLTAGE & CURRENT	
0 Channel 2 Disabled	
1 Direct (no post processing)	
2 Square Root of Channel 2	
3 Inverse of Channel 2	
4 Output Register 1 (smart module)*	
5 Output Register 2 (smart module)*	
6 Output Register 3 (smart module)*	
7 Output Register 4 (smart module)*	
*Note: The logic for CH2 is not the same as CH1, CH3, or CH4. The 1st and 3rd digits must both be set to 0. Selecting 040 to 070 in the 2nd digit of Code 4 directly selects one of the following settings in the output register map (3rd digit):	
2nd Digit	Output Register Map
4 selects	0 Averaged signal SENSOR 1
5 selects	1 Averaged signal SENSOR 2
6 selects	2 -
7 selects	3 -

17 If required enter Code 5 and select the required post processing settings for **CH3** in the 1st digit and the required register map settings in the 3rd digit.

CH3 Cod_5 X7X

FIRST DIGIT
CH3 POST PROCESSING
0 Direct Display of Input (no processing)
1 Square Root of Channel 3
2 Inverse of Channel 3
3 Meters with 4 kB memory NO Linearization Meters with 32 kB memory 32-point Linearization of CH3 using Table 3
Note: All linearization tables are set up in the Calibration Mode [24X].

THIRD DIGIT
OUTPUT REGISTER MAP
0 Averaged signal SENSOR 1
1 Averaged signal SENSOR 2
2 -
3 -
4 -
5 -
6 -
7 Smart input module register 1 code setup



Note the output register map is different for each smart input module type.

From Procedure 18, page 4

- 18 If required enter Code 6 and select the required post processing settings f or CH4 in the 1st digit and the required register map settings in the 3rd digit.

CH4 Cod_6 X7X

Press the [P] button to save the settings.

- 19 Press the [P] and [↑] buttons at the same time to return to the operational display.

FIRST DIGIT
CH4 POST PROCESSING
0 Direct Display of Input (no processing)
1 Square Root of Channel 4
2 Inverse of Channel 4
3 Meters with 4 kB memory
NO Linearization
Meters with 32 kB memory
32-point Linearization of CH4 using Table 4
Note: All linearization tables are set up in the Calibration Mode [24X].

To Procedure 17, page 3

Example Load Cell Setup Procedure

Our customer has an application that requires two load cells. The process requires a fast response sensor to monitor the assembly process on a conveyor belt and another to monitor the bin weight as it increases.

For example, configure the conveyor load cell as sensor 1 and the bin weight load cell as sensor 2. Select 50 Hz as the input line frequency and 20 Hz as the averaged output rate. Select a sensor input of 3 mV/V for sensor 1 and a sensor input of 20 mV/V for sensor 2. Configure sensor 1 to be read by CH1 and sensor 2 to be read by CH3.

- 1 Select 50 Hz as the input line frequency with a 20 Hz averaged output rate for both sensors. Select a 3 mV/V sensor input for SENSOR 1:

In [CODE 2] select [X77] then press [P] button.

Display toggles between [SM1] [000]

Set [SM1] to [223]

- 2 Select a 20 mV/V sensor input for SENSOR 2:

In [CODE 5] select [X77] then press [P] button.

Display toggles between [SM2] [000]

Set [SM2] to [XX3]

- 3 Select the CONVEYOR WEIGHT for CH1:

In [CODE 2] select [X70]

- 4 Select the BIN WEIGHT for CH3:

In [CODE 5] select [X71]

Customer Configuration Settings:

	1st Digit	2nd Digit	3rd Digit
577E1			
577E2			
CH1 Cod_2		7	
CH2 Cod_4	0		0
CH3 Cod_5		7	
CH4 Cod_6		7	

WARRANTY

Texmate warrants that its products are free from defects in material and workmanship under normal use and service for a period of one year from date of shipment. Texmate's obligations under this warranty are limited to replacement or repair, at its option, at its factory, of any of the products which shall, within the applicable period after shipment, be returned to Texmate's facility, transportation charges pre-paid, and which are, after examination, disclosed to the satisfaction of Texmate to be thus defective. The warranty shall not apply to any equipment which shall have been repaired or altered, except by Texmate, or which shall have been subjected to misuse, negligence, or accident. In no case shall Texmate's liability exceed the original purchase price. The aforementioned provisions do not extend the original warranty period of any product which has been either repaired or replaced by Texmate.

USER'S RESPONSIBILITY

We are pleased to offer suggestions on the use of our various products either by way of printed matter or through direct contact with our sales/application engineering staff. However, since we have no control over the use of our products once they are shipped, NO WARRANTY WHETHER OF MERCHANTABILITY, FITNESS FOR PURPOSE, OR OTHERWISE is made beyond the repair, replacement, or refund of purchase price at the sole discretion of Texmate. Users shall determine the suitability of the product for the intended application before using, and the users assume all risk and liability whatsoever in connection therewith, regardless of any of our suggestions or statements as to application or construction. In no event shall Texmate's liability, in law or otherwise, be in excess of the purchase price of the product.

Texmate cannot assume responsibility for any circuitry described. No circuit patent or software licenses are implied. Texmate reserves the right to change circuitry, operating software, specifications, and prices without notice at any time.

TEXMATE INC

1934 Kellogg Ave. • Carlsbad, CA 92008

Tel: 1-760-598-9899 • USA 1-800-839-6283 • That's 1-800-TEXMATE

Email: orders@texmate.com • Web: www.texmate.com

For product details visit www.texmate.com