





## Signal Conditioning Components



### ZERO Potentiometer (Pot) Optional


The Optional ZERO pot when installed is to the left of the SPAN pots (as viewed from the back of the meter). Typically it enables the displayed reading to be offset  $\pm 1000$  counts.



### SPAN Fine Potentiometer (Pot)

The 15 turn SPAN Fine pot is the middle pot (as viewed from the back of the meter). Typical adjustment is 20% of the input signal range.

## Component Layout



### RANGE SELECT Header

Range values are marked on the PCB. Three positions are provided. After selecting a new range with the single jumper clip, recalibration is required.

Changing the range to 20V or 200V full scale. The BN-45 comes standard as a 2VDC meter. The factory can recalibrate the meter to a different range either when the meter is ordered or as an after-sale service.


## Optional Face Plate Descriptors

AC	$\Omega$	kV	kVAR	m <sup>3</sup> /hr	Hz	RPM
V	mV	min	PF	F	C	Cos $\theta$
DC	x10kN	$\mu$ A	PSIG	mS	kg/cm <sup>2</sup>	psi
kW	W	kWH	pH	%	K	kPa
A	mbar	mA	MW	kA	RPS	MWH
mWs	$\mu$ m	kW/s	I	l/sec	ml	cm
ORP	mm/s	l/min	mm	kg/sec	lbs	kg/hr
FT	bars	min	m/min	Mvars	$\mu$ V	dB

P.N.: DU-CASEDES

To customize the face plate, clear adhesive label containing various popular descriptors may be ordered. Choose the descriptor desired, peel off the adhesive backing and align the descriptor in the center right of the faceplate.

## Connector Pinouts



**Display Test:** All numeric display segments will light up when Display Test Pin 6 is connected to Common Pin 3.

**Display Blank/Dim:** If Pin 4 is connected to Common Pin 3, the display will be blanked out. If a 1K $\Omega$  pot is connected between Pin 4 and Common Pin 3, the brightness of the display can be adjusted with the potentiometer.

**Hold Reading:** If Pin 5 is left unconnected, the meter will operate in a free-running mode. When Pin 5 is connected to the Hold/Test/Blank Common Pin 3, the meter will latch up. A/D conversions will continue, but the display will not be updated until the Hold Pin and Common pins are disconnected.

## Calibration Procedure

The BN-45 and BN-45I are calibrated at the factory with a precision DC voltage source. Whenever the range is changed, the meter needs to be recalibrated. The Span Potentiometer is accessible with the front cover of the meter removed for user calibration.


1. Make sure there is proper DC power and input.
2. Connect the power supply.
3. Apply a positive signal input equal to 95% of the full scale input.
4. Adjust Span Potentiometer in the front of the meter so that the displayed reading agrees with the signal input.
5. The BN-45/BN-45I is now calibrated and ready for use.

## Power Supply

The BN-45 ships from the factory with a non-isolated 5VDC power supply. For applications where isolation is required between the power and signal grounds, use the Texmate model BN-45I. This model is available with 9-36 VDC power options and generates an internally isolated supply.


**CAUTION - ELECTRICAL SHOCK HAZARD** All internal parts of the meter may be at the same electrical potential as the input signal and power supply. Do not reposition the signal conditioning components when input voltages are applied. When measuring dangerously high input voltages, extreme care must be taken to insulate the connector pins as well as all metal parts of the meter. A suitable high voltage warning notice should be affixed to those meters where there is any possibility that the meter could be removed from its case, or the internal components accessed, concurrent with the existence of a high voltage input signal.

# BN-45 Case Dimensions and Panel Cutouts




## PANEL CUTOUT

Case will mount in standard 1/16 DIN cutouts




Panel adaptor plates are available to retrofit most existing panel cutouts.

For additional strength, extra Mounting Slide Clips can be ordered and doubled up one behind the other. P/N:(75-DMT96X24)




When extra panel mounting tightness is required, optional Screw Mounting Clips are included which fit on the Mounting Slide Clips.


## FRONT VIEW



## SIDE VIEW



## TO REMOVE REAR COVER



## Ordering Information

### Standard Options for this Model Number

Part Number	Description
<b>►BASIC MODEL NUMBER</b> Includes plug in type screw terminals, standard display and standard power supply unless optional versions are ordered.	
BN-45 .....	4.5 digit Red LED, 2/20/200VDC, 5VDC Powered
BN-45I .....	4.5 digit Red LED, 2/20/200VDC, 5VDC Powered
<b>►DISPLAY</b>	
STANDARD .....	Red LED, 0.96 inch high. ....
BN-GREEN4 ..	Green LEDs, 0.56 inch high. ....
BN-BRIGHT ...	super bright Red LEDs, 0.56 inch high. ....

### Special Options and Accessories

Part Number	Description
<b>►SPECIAL OPTIONS (Specify Inputs &amp; Req. Reading)</b>	
Z50K .....	Zero offset 50 K Pot.
ZR .....	Range Change from Standard Range shown in BOLD Type. Please specify range when ordering.
ZS .....	Custom display scaling within standard range
<b>►ACCESSORIES</b>	
75-DMTC96X24 ...	.Side Slide Brackets, extra set (96x24mm only)
75-DBBZ96X24 ...	.Black Bezel for 96x24mm Case, BN and AM series
DN.CAS96X24 ...	.Din Case 96 X 24 Short Depth with Bezel

### WARRANTY

Texmate warrants that its products are free from defects in material and workmanship under normal use and service for a period of one year from date of shipment. Texmate's obligations under this warranty are limited to replacement or repair, at its option, at its factory, of any of the products which shall, within the applicable period after shipment, be returned to Texmate's facility, transportation charges pre-paid, and which are, after examination, disclosed to the satisfaction of Texmate to be thus defective. The warranty shall not apply to any equipment which shall have been repaired or altered, except by Texmate, or which shall have been subjected to misuse, negligence, or accident. In no case shall Texmate's liability exceed the original purchase price. The aforementioned provisions do not extend the original warranty period of any product which has been either repaired or replaced by Texmate.

### USER'S RESPONSIBILITY

We are pleased to offer suggestions on the use of our various products either by way of printed matter or through direct contact with our sales/application engineering staff. However, since we have no control over the use of our products once they are shipped, NO WARRANTY WHETHER OF MERCHANTABILITY, FITNESS FOR PURPOSE, OR OTHERWISE is made beyond the repair, replacement, or refund of purchase price at the sole discretion of Texmate. Users shall determine the suitability of the product for the intended application before using, and the users assume all risk and liability whatsoever in connection therewith, regardless of any of our suggestions or statements as to application or construction. In no event shall Texmate's liability, in law or otherwise, be in excess of the purchase price of the product.

Texmate cannot assume responsibility for any circuitry described. No circuit patent or software licenses are implied. Texmate reserves the right to change circuitry, operating software, specifications, and prices without notice at any time.



1934 Kellogg Ave. Carlsbad, CA 92008

Tel: 1-760-598-9899 • USA 1-800-839-6283 • That's 1-800-TEXMATE

• Email: orders@texmate.com • techsupport@texmate.com

• Web: www.texmate.com

**BN-45 Technical Manual Copyright © 2020 Texmate Inc. All rights reserved. Published by: Texmate Inc. USA. Information in this Technical Manual is subject to change without notice due to correction or enhancement. The information described in this manual is proprietary to Texmate, Inc. and may not be copied, reproduced or transmitted, in whole or in part, in connection with the design, manufacture, or sale of apparatus, device or private label product without the express written consent of Texmate, Inc.**

Copyright © 2020 Texmate Inc. All Right Reserved.