





LEOPARD FAMILY

DL-40

Leopard Panel Meter < 4 Digit 0.56" or 0.8" LEDs in a 1/8 DIN CASE

NOW FEATURING OPTIONAL PLUG-IN RELAY OR SSR **OUTPUT MODULES**

An economically smart programmable meter relay with isolated 4 to 20 mA retransmission or control loop output capability for measurement and control applications in a 96x48mm case.

General Features

0.8" red or green LED

- External transmitters or signal conditioners can be eliminated by direct connection of the sensor output to more than 38 Plug-in Input Signal Conditioners that include:
 - AC/DC Current Pressure - Resistance AC/DC Voltage - *Temperature Process - Load Cell Prototype - 4 to 20 mA
 - *See models DL-40H for higher accuracy digitally linearized thermocouple and RTD
- Optional isolated 16 bit analog output. User or factory scalable to 4 to 20 mA, 0 to 20 mA or 0 to 10 V across any desired digital span from ± one count to the full scale range of - 1999 to 9999 (12000 counts).
- Auto-sensing AC/DC power supply. For voltages between $85\text{-}265\,\text{V}$ AC / $95\text{-}370\,\text{V}$ DC (PS1) or $15\text{-}48\,\text{V}$ AC / $10\text{-}72\,\text{V}$ DC (PS2).
- 24 V DC excitation is available to power external transmitters and 5 or 10 V DC excitation is available for resistance bridge type sensors such as Load Cells and Pressure Transducers.
- Standard red or optional green or super bright red 4-digit LED with display range -1999 to 9999 (12000 counts).
- Red or green 0.8" LED large display option
- Four annunciator LEDs provide front panel alarm status indication for up to four setpoints.
- Two 10 Amp Form C and two 5 Amp Form A relays, or optionally four 5 Amp Form A relays are available.
- Automatic intelligent averaging smooths noisy signals, while providing a fast display response to real level changes.

Software Features

- Three-button programming from the front panel (UP, DOWN and PROGRAM buttons).
- Three front panel selectable ranges.
- Front panel selectable four-level brightness control of digital display, and setpoint LEDs.
- Four programmable setpoints.
- Relay activation can be selected to occur above (HI) or below (LO) each setpoint.
- Hysteresis setting for all four setpoints. Delay on make and delay on break for SP1 and SP2.
- · Peak and Valley. View and Reset.

Input Module Compatibility

LEOPARD FAMILY: More than 38 different Plug-in I-Series Input Signal Conditioners are approved for Texmate's Leopard Family of meters. Some examples are shown on pages 10 - 12. See www.texmate.com for an up to date listing.



LEOPARD

Specifications Input Specs: Depends on Input signal conditioner A/D Converter:14 bit single slope **Accuracy**: \pm (0.05% of reading + 2 counts) Temp. Coeff.:100 ppm/°C (Typical) Warm up time:2 minutes Conversion Rate:5 conversions per second (Typical) Display:.....4 digit 0.56" Red LED display (std), 0.56" or 0.8" Red, Green or Super Bright Red (optn) Range -1999 to 9999 counts. Polarity:Assumed positive. Displays – negative **Decimal Selection**:....Front panel button selectable, X•X•X•X• Positive Overrange:..Top segments of digital display flash Negative Overrange: Bottom segments of digital display flash Relay Output:Two 5 Amp Form A relays and two 10 Amp Form C, or 5 Amp form A relays. Analog Output:Isolated 16 bit user scalable mA or V

AIC (mA out)4-20 mA @ 0 to 500Ω max loop resistance AIV (volts out)0-10 V DC @ 500 Ω or higher resistance Power Supply:AC/DC Auto sensing wide range supply PS1 (std)85-265 VAC / 95-370 VDC @ 2.5W max 3.5W PS215-48 VAC / 10-72 VDC @ 2.5W max 3.5W

Operating Temp.:0 to 60 °C Storage Temp:-20 °C to 70 °C. Relative Humidity:95% (non condensing)

Case Dimensions:1/8 DIN, Bezel: 96x48 mm (3.78"x1.89") Depth behind bezel: 117 mm (4.61") Plus 11.8 mm (0.47") for Right-angled connectors, or plus 20 mm (0.79") for

Straight-thru connector.

Weight:6.5 oz., 8.5 oz when packed

Index			
Decimal Point & Brightness Selection	Digital Span Selection for Analog Range Output	I-Series Input Signal Conditioning Modules	Software Logic Tree

Controls and Indicators





Front Panel Buttons

Program Button

The P button is used to move from one program step to the next. When pressed at the same time as the button, it initiates the calibration mode. When pressed at the same time as the button, it initiates the setpoint setting mode.

Up Button

When in the operational display, pressing the • button alone, allows you to view and reset the Peak and Valley (Highest and Lowest Readings.)

When in the **calibration mode** or the **setpoint setting mode** the **b** button is used to increase the value of the displayed parameter.

Down Button

When in the operational display, pressing the ▶ button alone, allows you to view, but not change, the setting of setpoint 1,2,3 & 4. When in the **calibration mode** or the **setpoint setting mode** the ▶ button is used to decrease the value of the displayed parameter.

Glossary of Programming Symbols

To explain software programming procedures, logic diagrams are used to visually assist in following the programming steps. The following symbols are used to represent various functions and associated display elements of the meter:

Symbol

Explanation



This symbol represents the OPERATIONAL DISPLAY.



This is the PROGRAM button.



This is the UP button.



This is the DOWN button.




When a button is shown, press and release it to go onto the next step in the direction indicated by the arrow. When two or more buttons are shown, each with an arrow, this indicates that there is a number of programming choices.



When two buttons are shown side by side and enclosed by a dotted line, they must be pressed at the same time then released to go onto the next programming step.



If the display is shown with XXXX it means the value displayed will be the previously set value. When a number is shown it indicates the initial factory default setting or a specific "example number".




When two displays are shown together with bursts, this indicates that the display is toggling (flashing) between the name of the function and the value.



Text or numbers shown between square brackets in a procedure indicate the programming code name of the function or the value displayed on the meter display.




When the ♠ and ▶ buttons are shown together, the display value can be increased by pressing and releasing the ♠ button or decreased by pressing and releasing the ▶ button.



When the ♠ and ▶ buttons are shown with two displays, either display can be selected by pressing and releasing the ♠ or ▶ buttons.




When there are more than two display selections they are shown in brackets below the first display and are also selectable by pressing and releasing the or buttons.



A dotted box indicates these functions are omitted or bypassed when the related hardware is not present The DL-40 is an intelligent meter with a hierarchical software structure designed for easy programming and operation, as shown below in the software logic tree.

After the meter has been powered up, the four digits light up for three seconds and then settle to the operational display indicating the input signal.



15 Second Program Timeout

The meter has a 15 second program timeout. If no buttons are pressed for 15 seconds, at any stage of the programming sequence the meter will exit the programming mode and return to the operational display. Any program changes that were made prior to pressing the P button in the preceding step will not be saved.

Digital Calibration Mode

This mode enables the meter to be calibrated with an automatic scale factor calculation, by applying a high input signal, entering the desired reading for that signal, then applying a zero or low input signal, and then entering the desired 0 or low reading. The meter then automatically calculates and programs in the requisite scale factor, within the following parameters.

- 1. Positive and negative signals may be applied, but the difference between the high and the low signal inputs must be at least 1000 counts or Err will be indicated.
- 2. Positive and Negative values for the desired reading can be entered, but the scale factor created can not exceed the Digital Display Span capability of the meter which is 12,000 counts between –1999 to 9999.
- 3. The internal Signal Span is limited to 3 V DC between 1 V DC to + 2 V DC. Any outputs from an Input Signal Conditioning module that exceed these limits will cause the meter to indicate overrange regardless of the Digital Display Span scaled.

Note: Most input signal conditioners have provisions for analog calibration and scaling. If the meter's digital scale factor is set to read zero with a zero input (shorted input), and to read 1000 with a 1.000 V input, any pre-calibrated signal conditioner with an output that does not exceed -1 V to +2 V, will read correctly in the meter without any further calibration.

Digital Calibration Procedure

STEP A Enter the Calibration Mode

- 1) Press the ₱ and ₱ buttons at the same time. Display toggles between [cAL] and [oFF].
- Press the or button.
 Display changes from [oFF] to [on].
- 3) Press the P button. Display toggles between [ZEro] and the previous zero setting.

STEP B Select Between Two Point Digital Calibration of Input Signal and Two Point Analog Output

Note: If the analog output option is not present, Step B is skipped and the program goes directly from Step A to Step C.

- 2) Press the D button. Display toggles between [ZEro] and the previous zero setting.

STEP C Set the Meter's Low Input Signal Reading on the Digital Display

- Apply a zero or low signal to the meter. (Positive or negative values are allowed)
- 2) Using the **1** and **1** buttons, adjust the meter display to the desired reading for the applied low input signal.
- 3) Press the D button. Display toggles between [SPAn] and the previous span setting.

STEP D Set the Meter's High Input Signal Reading on the Digital Display

- 1) Apply a high input signal to the meter.
- 2) Using the 1 and 1 buttons, adjust the digital display to the desired reading for the applied high input signal.
- 3) Press the P button.

The Digital Calibration Procedure Mode is Now Complete.


If the digital calibration was successfully completed, the menu branches to the DISPLAY FUNCTION CONFIGURATION MODE, (see page 7) and the display flashes [dP] and the previous setting.

ERROR Indicates Unsuccessful Calibration

If the calibration was unsuccessful, the display indicates [Err], the new calibration settings just entered will not take effect and the previously stored setting will remain.

The three most likely causes of an error during calibration are:

- The full scale and zero signals were too similar. The full scale signal must be at least 1000 counts greater than the zero or low input signal (positive and negative values are allowed).
- The scaling requirement exceeded the capability of the meter (–1999 to 9999).
- 3) No input signal present, or incorrect connections.



Two Point Analog Output Range Setting and Calibration

STEP A Enter the Calibration Mode

- 1) Press the ℙ and ◑ buttons at the same time. Display toggles between [cAL] and [oFF].
- 2) Press the

 or

 button. Display changes from [oFF] to [on].
- 3) Press the P button. Display toggles between [cAL] and [out] input calibration.

Note: If at this point the display skips directly to toggle between [SPAn] and the previous [SPAn], the software is detecting that the optional analog output hardware is NOT installed.

STEP B Enter the Analog [oUT] Output Mode

1) Press the P button. Display toggles between [cLo] and an internal scale factor.

STEP C Set or Calibrate the [cLo] Low Analog Output Range

- 1) Select the voltage or current loop output header position on the output module. (See Component Layout on page 9).
- 3) Press the P button. Display toggles between [chi] and an internal scale factor.

STEP D Set or Calibrate the [chi] High Analog Output Range

- 1) Using the 1 and 1 buttons, adjust the analog output to the desired high value as shown on the multimeter display. chi may be adjusted to any value from 17 mA to 21 mA (mA output selected) or from 8 V to 10.3 V (volt output selected)
- 2) Press the P button. The display exits the calibration mode and returns to the operational display.

Note: Having established the Low and High range of the analog output, the digital span can now be selected which will set the two digital points between which the analog output will occur. (See Digital Span Selection below).

Decimal Point and Brightness Selection

Enter the Decimal Point and Brightness Mode Through the Sub Menu [CAL] [oFF]

- 2) Press the P button. Display shows previous [dp] selection.

STEP E Set the Decimal Point

- Using the

 and

 adjust the display to the desired decimal point setting.
- 2) Press the P button. Display toggles between [Br] and the previous [Br] setting.

STEP F Set the Display Brightness

- 1) Using the **1** and **1** buttons, adjust the display to the desired brightness setting (4 is the brightest setting).
- 2) Press the P button. Display brightness changes to new setting and display toggles between [Anhi] and the previous [Anhi] setting.

Digital Span Selection for Analog Range Output


STEP G Setting the Digital Span Point for Analog High Output

- 1) Using the 1 and 1 buttons, adjust the display to the desired digital value which sets the point at which the selected analog high output range will occur.
- 2) Press the D button. Display toggles between [AnLo] and previous [AnLo] setting.

STEP H Setting the Digital Span Point for Analog Low Output

- 1) Using the 1 and 1 buttons, adjust the display to the desired digital value which sets the point at which the selected analog low output range will occur.
- 2) Press the 🗈 button. The display exits the calibration mode and returns to the operational display.

Note: Any two digital scale points from –1999 to 9999 can be selected. The digital scale points for analog high and analog low can be reversed for reversed 20-4 mA output. The span of the digital scale can be as small as two counts however small spans cause the 16 bit D to A to increment in stair case steps.



Setpoint Setting and Relay Configuration Mode

The following programming steps are required to enter the setpoint values and configure the relay functions in a meter with four relays using four setpoints. Generally if less than four relays are installed the software auto detects missing relays and deletes reference to them from the menu. In some cases setpoints without relays are operational for display only purposes.

STEP A Enter the Setpoint Mode

STEP B Set Setpoint 1 (SP1)

- 1) Using the **1** and **1** buttons, adjust the display to the desired SP1 value.
- 2) Press the D button. Display toggles between [doM] and the previous [doM] setting.

STEP C Set the SP1 Delay-on-Make (doM) Delay Time Setting

- 1) Using the

 and

 buttons, adjust the display to the desired [doM] value

 (0 to 9999 seconds). The reading must continuously remain in an alarm condition

 until this delay time has elapsed before the relay will make contact (energize).
- 2) Press the 🗓 button. Display toggles between [dob] and the previous [dob] setting.

STEP D Set the SP1 Delay-on-Break (dob) Delay Time Setting

- 1) Using the 1 and 1 buttons, adjust the display to the desired [dob] value (0 to 9999 seconds). The reading must continuously remain in an non-alarm condition until this delay time has elapsed before the relay will break contact (de-energize).
- 2) Press the P button. Display toggles between [hYSt] and the previous [hYSt] setting.

STEP E Set the Hysteresis Setting for Setpoint 1

- 1) Using the

 and

 buttons, adjust the display to the desired hysteresis [hYSt] value.
- 2) Press the P button. Display toggles between [SP2] and the previous [SP2] setting. **NOTE**: Half of the Hysteresis value selected is applied above and below the setpoint.

NOTE: Steps F, G, H and J have functionally the same procedure as steps B, C, D, and E shown above.

STEP F Set Setpoint 2 (SP2)

- STEP G Set the SP2 Delay-on-Make (doM) Delay Time Setting
- STEP H Set the SP2 Delay-on-Break (dob) Delay Time Setting

STEP I Set the Hysteresis Setting for Setpoint 2

- 1) Using the **1** and **1** buttons, adjust the display to the desired hysteresis [hYSt] value.
- 2) Press the D button. Display toggles between [SP3] and the previous [SP4] setting.

STEP J Set Setpoint 3 (SP3) (No [doM] or [dob])

- 1) Using the **1** and **3** buttons, adjust the display to the desired SP3 value.
- 2) Press the D button. Display toggles between [hYSt] and the previous [hYSt] setting.

STEP K Set the Hysteresis Setting for Setpoint 3

- 1) Using the **1** and **1** buttons, adjust the display to the desired hysteresis [hYSt] value.
- 2) Press the D button. Display toggles between [SP4] and the previous [SP4] setting.

STEP L Set Setpoint 4 (SP4) (No [doM] or [dob])

- 1) Using the **1** and **1** buttons, adjust the display to the desired SP4 value.
- 2) Press the P button. Display toggles between [hYSt] and 0.

STEP M Set the Hysteresis Setting for Setpoint 4

- Using the

 and

 buttons, adjust the display to the desired hysteresis [hYSt] value.
- 2) Press the P button. Display toggles between [rLYS] and the previous relay setting.

STEP N Set Relay Activation mode [rLYS]


- (h) High the relay energizes when the setpoint is exceeded. (L) Low the relay energizes below the setpoint. The setpoint is indicated from left to right SP1, SP2, SP3, SP4.
- 1) Using the **1** and **1** buttons, adjust the reading on the display to the desired relay settings: [LLLL], [LhLh], [Lhhh], [hhhh].

If only 2 relays installed [Lh] [hL] [hh] [LL].


2) Press the P button.

The meter exits the setpoint mode and returns to the operational display.

The Setpoint Relay programming mode is now complete.



Functional Diagram



Connector Pinouts


Pinout Diagram

The Rear View of the Meter diagram shows the meter with the relay configuration: dual 10 Amp Form C and dual 5 Amp Form A relays. An analog output module is also shown as installed.


The DL-40 uses plug-in type screw terminal connectors for all input and output connections. The power supply connections (pins 14 and 15) have a unique plug and socket outline to prevent cross connection. The main board and input signal conditioner use rightangled connectors as standard. The output module uses straightthru connectors as standard.



WARNING: AC and DC input signals and power supply voltages can be hazardous. Do Not connect live wires to screw terminal plugs, and do not insert, remove or handle screw terminal plugs with live wires connected.



Auto-sensing AC/DC power supply. For voltages between 85-265 V AC / 95-370 V DC (PS1) or 18-48 V AC / 10-72 V DC (PS2). Standard plug-in screw terminal connectors provided by Texmate:



Input Signal – Pins 1 to 6

Pins 1 to 6 are reserved for the input signal conditioner. See the data sheet for the selected input signal conditioner.

Pins 8 to 12 - Relay Output Pins

Note: If relays for setpoints 1 & 2 are installed on the main board, and a relay output module is used that also has relays in the setpoints 1 & 2 positions, the duplicate relays will operate in unison.

SP1 NO. Normally Open 5 Amp Form A. Pin 8 Pin 9

SP2 NO. SP2 NO. Normally Open 5 Amp Form A. Pin 10 Pin 11

Pin 12 NO CONNECTION.

Pins 14 and 15 – AC/DC Power Input
Auto-sensing AC/DC power supply. For voltages between 85-265 V AC/95-370 V DC (PS1) or 18-48 V AC/10-72 V DC (PS2). Pin 14 AC/DC Neutral. Neutral power supply line.

Pin 15 AC/DC line. Live power supply line.

Optional Carrier Board Output Pins

Pins 16 and 17 - Analog Output

Pins 16 and 17 are the analog output pins on the optional output module. Their pin definitions are:

Pin 16 Positive (+) analog output. Negative (-) analog output. **Pin 17**

Connector Pinouts continued

Pins 18 to 21 - Rear Panel Function Pins

Pins 18 to 21 provide functions that can be implemented with an external switch. Their pin definitions are:


- **Pin 18 DIM.** By connecting the display dim (DIM) pin to the COMMON pin, the display brightness setting is halved.
- Pin 19 COMMON. To activate the LOCK or DIM functions from the rear of the meter, the respective pins have to be connected to the COMMON pin. This pin is connected to the internal power supply ground.
- internal power supply ground.

 Pin 20 HOLD. By connecting the HOLD pin to the COMMON pin, the displayed reading is frozen, however, A/D conversions continue. When the HOLD pin is disconnected from the COMMON pin, the correct reading is displayed.
- pin, the correct reading is displayed.


 Pin 21 LOCK. By connecting the LOCK pin to the COMMON pin, the meter's programmed parameters can be viewed but not changed.

Pins 22 to 29 - Output Module Pins


Relay Modules with 4 Independent 400V (210mA DC only) or (140mA AC/DC) SSRs




Relay Modules with 2 Non-Isolated 5A Form A Relays, and 2 Non-Isolated 10A Form C Relays




Relay Modules with 4 Isolated 5A Form A Relays




Component Layout




Display Board - Front View




0.56" LED Display Board - Front View




0.8" LED Display Board - Front View



High Volt Main Board



Output Module Carrier Board




I-Series Input Signal Conditioning Modules

Many additional input modules are available and others are constantly being developed. Check with your local distributor or www.texmate.com for updated information.

Pre-calibrated **I-Series** input modules, that have span or zero potentiometers, can be interchanged between any **I-Series** compatible meter, without recalibration, because all of the analog scaling and reference circuitry is self-contained within the module. Where appropriate, all the standard ranges shown are designed to be header selectable by the user, and Texmate's unique SPAN ADJUST Header facilitates scaling to almost any required engineering unit. See Input Module Component Glossary and Calibration on pages 13 and 14. Also see Two Point Digital Calibration and Digital Calibration on page 4.


Unless otherwise specified Texmate will ship all modules pre-calibrated with factory preselected ranges and/or scalings as shown in **BOLD** type. Other pre-calibrated standard ranges or custom ranges may be ordered. Factory installed custom scaling and other custom options are also available (see Ordering Information, Special Options on last page).






WARNING: AC and DC input signals and power supply voltages can be hazardous. Do Not insert, remove or handle modules with live wires connected to any terminal plugs.


IAO1: AC Volts Scaled RMS, 200/600V AC




IAO2: AC Volts Scaled RMS, 200mV/2V/20V AC




IAO3: AC Milliamps Scaled RMS, 2/20/200mA AC




IAO4: AC Amps Scaled RMS, 1 Amp AC IAO5: AC Amps Scaled RMS, 5 Amp AC




IAO6: AC Volts True RMS, 300/600V AC




IAO7: AC Volts True RMS, 200mV/2V/20V AC




IAO8: AC Milliamps True RMS, 2/20/200mA AC



IAO9: AC Amps True RMS, 1 Amp AC IA11: AC Amps True RMS, 5 Amp AC




IA10 AC Millivolts, Scaled RMS, 100mV AC




I-Series Input Signal Conditioning Modules


IA12: AC Millivolt RMS Sigma Delta




IDO1: DC Volts, 2/20/200V/Custom w/24V DC Exc




IDO2: DC Millivolts, 20/50/100/200mV DC w/24V DC Exc




IDO3: DC Milliamps, 2/20/200mA DC w/24V DC Exc




IDO4: DC Amps, **5A DC** IDO9: DC Amps, **1A DC**




ID05: DC Volts **2**/20/200/Custom V DC with Offset and 24V Exc.




ID07: DC Milliamps, 2/20/200mA DC with Offset




IF02: Line Frequency



IGYZ: Universal Direct Pressure (Absolute or Differential/Gage)
See below for ordering code options




Ordering Code Options for Direct Pressure (IGYX, IGYY & IGYZ)




For Single Channel IGYX with two digital inputs, the last digit of order code is always X.

For Universal Direct Pressure IGYZ, the last digit of order code is always Z.

IP01: Process Loop, **4-20mA** IP02: Process Loop, **4-20mA** with 24VDC EXC




IPO3: Process Input, 1-5V DC with Offset, 24V Exc




I-Series Input Signal Conditioning Modules


IP07: Universal Process Input




IPT1: Prototype Board for Custom Design




IRO2: 3 wire Potentiometer 1K min (0-F.S.)




IR03: Linear Potentiometer 1K Ω min




IR04: Resistance 2K Ω (Lynx only) IR05: Resistance 2K Ω (Leopard only)




ISO1: Strain Gage 5/10VDC Exc., 20/2mV/V, 4/6-wire ISO2: Pressure/Load Cell




ISO4: Pressure/Load Cell Ext Exc., 20/2mV/V, 4/6-wire




ISO5: Pressure/Load Cell 20/2mV/V, 5/10V Exc 4-wire




ISO6: Pressure/Load Cell Ext Exc., 20/2mV/V, 4-wire




ISO7: Pressure/Load Cell Ext Exc. High Impedance,




IT03: RTD, 100 Pt. 2/ **3**/4-wire (-200 to 800°C) **IT04:** RTD, 100 Pt. 2/ **3**/4-wire (-200 to 1470°F) **IT05:** RTD, 100 Ω Pt. 2/**3**/4-wire (-199.9 to 199.9°F) **IT14:** RTD, 100 Ω Pt. 2/**3**/4-wire (-199.9 to 199.9°C)



IT06: Thermocouple, J Type (0-1400 °F) IT08: Thermocouple, J Type (0-760 °C)



IT07: Thermocouple, K Type (0-1999 °F) IT09: Thermocouple, K Type (0-1260 °C)



For higher accuracy digitally linearized RTD (P385 or P392) and Thermocouples (J/K/R and T), see the special Leopard Temperature meters DL-40H(1/8 DIN) and BL-40H(1/16 DIN) which use only two special thermocouple modules which are not compatible with regular Leopard Family meters.

 $\begin{array}{ll} \textbf{IT-10} & \text{Thermocouple J/K/R/T, °C/°F, 1°/0.1° resolution} \\ \textbf{User Selectable Accuracy $\pm 0.05\% + 2 digits.} \\ \textbf{IT-11} & \text{RTD } 100\Omega \text{ Pt , 3/4 wire, °C/°F, 1°/0.1° resolution} \\ \textbf{User Selectable Accuracy $\pm 0.05\% + 2 digits.} \\ \end{array}$



Input and Output Pins

On most modules Pin 1 is the Signal High input and Pin 3 is the Signal Low input. Typically Pin 2 is used for Excitation Voltage output.



24V DC Output Header

On some modules this header enables a 24V DC 25mA (max) Excitation/Auxiliary output to be connected to Pin 2.

INPUT RANGE Header



Range values are marked on the PCB. Typically two to four positions are provided, which are selected with either a single or multiple jumper clip. When provided, a custom range position is only functional when the option has been factory installed.




SPAN Potentiometer (Pot)

If provided, the 15 turn SPAN pot is always on the right side (as viewed from the rear of the meter). Typical adjustment is 20% of the input signal range.

SPAN ADJUST Header




This unique five-position header expands the adjustment range of the SPAN pot into five equal 20% steps, across 100% of the input Signal Span. Any input Signal Span can then be precisely scaled down to provide any required Digital Display span from 1999 counts to 001 (one count).



SPAN RANGE Header



When this header is provided it works in conjunction with the SPAN ADJUST Header by splitting its adjustment range into a Hi and a Lo range. This has the effect of dividing the adjustment range of the SPAN pot into ten equal 10% steps across 100% of the input Signal Span.





ZERO Potentiometer (Pot)


If provided, the ZERO pot is always to the left of the SPAN pot (as viewed from the rear of the meter). Typically it enables the input signal to be offset $\pm 5\%$ of full scale (-100 to +100 counts).



ZERO OFFSET RANGE Header




When provided, this three position header increases the ZERO pot's capability to offset the input signal, to $\pm 25\%$ of the digital display span. For example a Negative offset enables a 1 to 5V input to display 0 to full scale. The user can select negative offset, positive offset, or no offset (ZERO pot disabled for two step non-interactive span and offset calibration).



ZERO ADJUST Header



When this header is provided, it works in conjunction with the ZERO OFFSET RANGE Header, and expands the ZERO pot's offset capability into five equal negative steps or five equal positive steps. This enables virtually any degree of input signal offset required to display any desired engineering unit of measure.



Input Module Analog Calibration

In addition to the analog calibration capabilities that enable many modules to be interchanged between different meters without loss of accuracy the Leopard Family of meters have enhanced Digital Calibration functions. See Page 4

Basic standard range calibration of direct reading modules that utilize either Auto Zero or a ZERO pot, an INPUT RANGE Header and or a SPAN pot.

- 1 If the module has an INPUT RANGE Header, reposition the jumper clip to select the desired input signal range.
- Apply a zero input or short the input pins. The display will auto zero, or if the module has a ZERO pot, it should be adjusted until the display reads zero.
- 3 Apply a known input signal that is at least 20% of the full scale input range and adjust the SPAN pot until the display reads the exact input value. For negative inputs, Leopard Family Meters will display negative overrange at 50% of full scale range.
- 4 Decimal Points. The selection or positioning of decimal points has no effect on the calibration of the modules

Wide range scaling, in engineering units not requiring offsets, with modules that utilize auto-zero or a ZERO pot, a SPAN RANGE Header and or a SPAN ADJUST Header.

Texmate's unique SPAN ADJUST and SPAN RANGE Headers provide the circuit equivalent of an ultra-precision one megohm 75 or 150 turn potentiometer that can infinitely scale down any Input Signal SPAN to provide any full scale Digital Display Span from 1999 (counts) to 001 (one count).

Input Module Calibration Procedures Continued

If the module has an INPUT RANGE Header, and the required full scale Digital Display Span (counts) is to be larger than the directly measured value of the input Signal Span, then the next lower range on the INPUT RANGE Header should be selected. The resulting over range Signal Span is then scaled down, by selecting the position of the SPAN RANGE Header and or the SPAN ADJUST Header, which will reduce the input Signal Span to a percentage, that the required Digital Display Span can be reached by calibration with the SPAN pot.

Example A: 0 to 10 V to read 0 to 1800 gallons. Signal Span = 10V, Digital Display Span = 1800 counts

- 1 Select the 2 V INPUT RANGE Header position. This will provide a digital display of 1800 counts with an input of only 1.8 V which is (1.8÷10)=18% of the examples 10 V Signal Span.
- 2 To scale down the Signal Span to 18% select the 20% Signal Span position on the SPAN ADJUST Header (position 1) or if the module has a SPAN RANGE Header, select (LO Range) and 20% Signal Span position on the SPAN ADJUST Header (position 2).
- 3 Apply a zero input or short the input pins. The display will auto zero, or if the module has a ZERO pot, it should be adjusted until the display reads zero.
- 4 Apply 10 V and adjust the SPAN pot until the display reads 1800.

Large offset scaling and calibration of process signal inputs with modules that utilize ZERO ADJUST Headers and or ZERO OFFSET RANGE Headers.

Texmate's unique ZERO OFFSET RANGE Header enables the use of a simple two step scaling and calibration procedure for those process signals that require large offsets. This eliminates the back and forth interaction, between zero and span settings, that is often required to calibrate less finely engineered products.

The first step is to set the ZERO OFFSET RANGE Header to the center position (No Offset) and scale down the Input Signal Span to a percentage that will enable calibration with the SPAN pot to reach the required Digital Display Span.

The second step is to set the ZERO ADJUST and or ZERO OFFSET RANGE Header to provide a positive or negative offset of sufficient counts that calibration with the ZERO pot will offset the Digital Display Span to produce the required digital reading.

Example B: 1 to 5 V to read -100 to 1500 °C.


Signal Span = 4V, Digital Display Span = 1600 counts

- 1 If the module has an INPUT RANGE Header the 2 V position should be selected. This will provide a digital display of 1600 counts for an input of 1.6 V which is $(1.6 \div 4) = 40\%$ of the examples 4 V signal span. To scale down the Signal Span to 40% select the 40% Signal Span position on the SPAN ADJUST Header (position 2).
- 2 If the module is a Process Input 1-5 V DC type, select the (Hi Range) position on the SPAN RANGE Header and the 100% Signal Span position on the SPAN ADJUST Header (position 5, max increase). This will provide a digital display of 1600 counts for an input of 4V which is 100% of the examples 4V Signal Span.
- 3 Set the ZERO OFFSET RANGE Header to the center position (no offset). Apply 1 V and adjust the SPAN pot until the display reads 400. A 4V input would then read 1600 counts.
- 4 Set the ZERO OFFSET RANGE Header to the negative offset position. If the module has a ZERO ADJUST Header select the position that will provide a negative offset of ≈ −500 counts. Apply 1 V and adjust the ZERO pot until the display reads −100. Apply 5 V and check that the display reads 1500.

Example C: 4 to 20 mA to read 00.0 to +100.0% Signal Span = 16 mA, Digital Display Span = 1000 counts.

- 1 The full scale Signal Span of the Process Input 4-20 mA modules is 0 to 20 mA for a full scale Digital Display Span of 0 to 2000 counts. This will provide a digital display of 1000 counts with an input of only 10 mA which is (10÷16)=62.5% of the examples 16 mA signal span.
- 2 To scale down the Signal Span to 62.5% select the (Hi Range) Position on the Span Range Header and the 70% Signal Span position on the SPAN ADJUST Header (position 2).
- 3 Set the ZERO OFFSET RANGE Header to the center position (no offset). Apply 4 mA and adjust the SPAN pot until the display reads 250. A 16 mA input would then read 1000 counts.
- 4 Set the ZERO OFFSET RANGE Header to the positive offset position. If the module has a ZERO ADJUST Header select the position that will provide a negative offset of ≈ −250 counts. Apply 4 mA and adjust the ZERO pot until the display reads 000. Apply 20 mA and check that the display reads 1000. Select decimal point XXX•X to display 00.0 to 100.0.


Case Dimensions



Lens Cover OP-N4X/96X48

The lens cover is designed to be dust and water proof to NEMA-4 standards. The lens cover consists of a base and cover with a cam hinge and key-lock locking device.


An O-ring, or neoprene gasket forms a seal between the base and the panel. The cam hinge prevents the cover from closing when opened until pushed closed. The cover has a tapered recess that, when closed, forms a capillary seal with a tapered ridge on the base. Turning the key-lock tightens the cover to the base, ensuring seal integrity. A safety catch keeps the cover closed even when the key is turned to the open position and removed. The keyhole can also be used to attach a safety seal clip, preventing unauthorized opening.



Metal Surround Case OP-MTL96X48

The meter's plastic case is made from fire retardant polycarbonate. A metal surround case can be ordered to enhance the meter's fire retardant capabilities and also provide shielding against electromagnetic interference (EMI). The metal case slides over the polycarbonate case and is held firmly in place by spring-type non-return clips. Once the metal case has been fitted to the polycarbonate case it cannot be removed. With the metal case in place, the meter's plastic ratchet-type mounting clips can no longer be used. A pair of screw-type mounting clips are inserted into holes on the side of the metal case and used to mount the meter in the panel. A ground tab on the metal case provides a ground connection between the meter's main board and the metal case.

* Metal Surround Case must be factory installed.



Ordering Information BASIC MODEL # DISPLAY POWER SUPPLY INPUT MODULES **ANALOG OUTPUT* RELAY OUTPUT* OPTIONS / ACCESSORIES** DL-40

Add to the basic model number the order code suffix for each standard option required. The last suffix is to indicate how many different special options and or accessories that you may require to be included with this product. *Except when when R1 or R2 relay output is selected, a meter ordered with an analog output or a relay output module requires an Output Module Carrier Board which should be automatically included with the order, with an additional charge. (See special Options and Accessories section)

Ordering Example: DL-40-DR-PS1-IA01-AIC-R1-OA2, the 2 OA's are, CR-CHANGE and a OP-N4X/96X48

▶ BASIC MODEL NUMBER

DL-4096x48, Leopard, 4 Digit

Standard Options for this Model Number

Order Code Suffix

Description

► DISPLAY
DR Red LED, 0.56 inch high
DB Super-bright Red LED, 0.56 inch high DG .Green LED, 0.56 inch high .Large Green LED, 0.8 inch high

Large Red LED, 0.8 inch high

▶ POWER SUPPLY

....**85 - 265VAC / 95 - 370VDC**18 - 48VAC / 10 - 72VDC

► INPUT MODULES (Partial List. See www.texmate.com)

Unless otherwise specified Texmate will ship all modules precalibrated with factory preselected ranges and/or scalings as shown in **BOLD** type

```
AC-Volts Scaled RMS, 200/600V AC
AC-Volts Scaled RMS, 200mV/2V/20V AC
AC-Volts Scaled RMS, 200mV/2V/20V AC
AC-MA Scaled RMS, 2/20/200mA AC
AC-MA Scaled RMS, 0-1 Amp AC (0-100.00)
AC-Amps Scaled RMS, 0-5 Amp AC (0-100.00)
AC-Amps Scaled RMS, 0-5 Amp AC (0-100.00)
AC-Volts True RMS, 200/600V AC
AC-Volts True RMS, 200/800V AC
AC-MB True RMS, 2/20/200mA AC
AC-MB True RMS, 0-1 Amp AC (0-100.00)
AC-Millivolt, Scaled RMS, 100mV AC
AC-Amps True RMS, 0-1 Amp AC (0-100.00)
AC-Millivolt, True RMS, 100mV AC
DC-Volts, 2/20/200V/Custom W/24V DC Exc
DC-Milliwolt, 710 RMS, 100mV AC
DC-Willimp, 2/20/200mA DC W/24V DC Exc
DC-Millimp, 2/20/200mA DC W/24V DC Exc
DC-Millimp, 2/20/200mA DC W/0ffset and 24V Exc
IA02
IA03
    IA04
IA05
    IA06
    IA07
IA08
    IA10
IA11
IA12
    ID01
ID02
    ID03
ID04
ID05
ID07
ID09
IF02
```

| FO2 | Line Frequency, 3u-3uvvac, 177.712, of options |
| GYZ* | Universal Direct Pressure |
| *View the IG- Ordering Code on page 11 to determine the value for Y & Z (IGAZ to IGKZ) |
PD1	Process Loop, 4-20mA(0-100.00)	
P02	Process Input, 1-5V DC(0-100.00) w/24VDC Exc	
P03	Process Input, 1-5V DC(0-100.00) w/Offset, 24V Exc	
P07	Universal Process 2V/5V/10V/20V/200V/2mA/20mA/Custom	
P11	Prototype Board for Custom Design	
R02	3-Wire Potentiometer	KΩ min (0-F.S.)
R03	Linear Potentiometer, 3-wire, 1KΩ min	
Resistance 2KΩ	Junear Ordentioneter 13-wire, 1KΩ min	
Resistance 2KΩ

Strain Gage 5/10VDC Exc., 20/2mV/V, 4/6-wire
Pressure 5/10VDC Exc., 20/2mV/V, 4/6-wire
Pressure 5/10VDC Exc., 20/2mV/V, 4/6-wire
Pressure/Load Cell 20/2mV/V, 5/10V Exc 4-wire
Pressure/Load Cell 20/2mV/V, 5/10V Exc 4-wire
Pressure/Load Cell Ext Exc., 20/2mV/V, 4-wire
Pressure 20/2mV/V with High Impedance and External Excitation
RTD, 100Ω Pt. 2/3/4-wire (-200 to 800°C)
RTD, 100Ω Pt. 2/3/4-wire (-200 to 1470°F)
RTD, 100Ω Pt. 2/3/4-wire (-190.0 to 199.0°F)
Thermocouple, J Type (0-1400°F)
Thermocouple, K Type (0-1400°C)
Thermocouple, K Type (0-160°C)
RTD, 100Ω Pt. 2/3/4-wire (-199.0 to 199.0°C) IR05 IS01 IS02 IS04 IS05 IS06 **IS07** IT03 IT04 IT05 IT06 IT07 IT08

► ANALOG OUTPUT

Isolated 16 Bit Current Output, 0-20mA and 4-20mA, pls. specify

.Isolated 16 Bit Voltage Output, 0-10VDC

Texmate warrants that its products are free from defects in material and workmanship under normal use and service for a period of one year from date of shipment. Texmate's obligations under this warranty are limited to replacement or repair, at its option, at its factory, of any of the products which shall, within the applicable period after shipment, be returned to Texmate's facility, transportation charges pre-paid, and which are, after examination, disclosed to the satisfaction of Texmate to be thus defective. The warranty shall not apply to any equipment which shall have been repaired or altered, except by Texmate, or which shall have been subjected to misuse, negligence, or accident. In no case shall Texmate's liability exceed the original purchase price. The aforementioned provisions do not extend the original warranty period of any product which has been either repaired or replaced by Texmate.

Note: R1 and R2 are located on the main board, and are generally used when only two Form A Relays or less are required and an Analogy Output is not required R1 Single 5A Form A Relay

.Dual 5A Form A Relays

► RELAY OUTPUT MODULES

Note: If a meter is ordered with a Relay Output Module, but without Analog Output, an Output Module Carrier Board should be automatically added to the order.

```
and should be automatically added to the order.

One 10 Amp Form C Relay, Isolated

One 10 Amp Form C and Two 5 Amps Form A Relays

One 10 Amp Form C and One 5 Amp Form A Relays

Two 10 Amp Form C and Two 5 Amps Form A Relays

Two 10 Amp Form C and Two 5 Amps Form A Relays

Two 10 Amp Form C and One 5 Amp Form A Relay, Isolated

One 5 Amp Form A Relay, Isolated

Two 5 Amp Form A Relays, Isolated

Three 5 Amp Form A Relays, Isolated
 OR16
 OR12
 OR23
 OR31
 OR33
OR34
```

Solid State Relay (SSR) Output Modules DC Only
OR51 ...One 400V DC Solid State Relay (SSR) 210mA
OR52 ...Two 400V DC Solid State Relays (SSR) 210mA
OR53 ...Three 400V DC Solid State Relays (SSR) 210mA
OR54 ...Four 400V DC Solid State Relays (SSR) 210mA

Solid State Relay (SSR) Output Modules AC/DC
OR61 ... One 400V AC/DC Solid State Relay (SSR) 140mA
OR62 ... Two 400V AC/DC Solid State Relays (SSR) 140mA
OR63 ... Three 400V AC/DC Solid State Relays (SSR) 140mA
OR64 ... Four 400V AC/DC Solid State Relays (SSR) 140mA

Special Options and Accessories (OA's)

Part Number

COR-INSTI

Description

Installation - Relays in non-standard locations , specify serial # COR-

► SPECIAL OPTIONS (Specify Inputs or Outputs & Req. Reading) Output Module Carrier Board

One carrier board must be ordered with any meter that includes any one or more of the following

options: Analog Output and/or Relay Output Modules. SA-DL/OM-CB Output Module Carrier Board, DL series CR-CHANGE Range Change from Standard Range shown in BOLD type Custom display scaling within standard ranges Custom scaling of analog output for digital meters & bargraphs .NRC to set-up Custom Configuration file and issue serial # CS-3/3.5/4 . COA-3/3.5/4 CCL-SETUP CCL-INSTL CSR-SETUP Installation of custom configuration, specify serial #CCL-.NRC to set-up custom selectable range CSR-INSTL .Factory installation - custom configuration, specify serial # CSR-.NRC to set-up custom special scaling .Installation - for 3.5 and 4.0 meters, specify serial # CSS-CSS-SETUP . CSS-34/INSTL COR-SETUP .NRC to set-up Relays in non-standard locations

▶ ACCESSORIES (Specify Serial # for Custom Artwork Installation)
75-DBBZ9648F ...Black Bezel for 96x48mm Case
75-DMTCLIPF ...Side Slide Brackets (2 pc) - extra set, extra strength
76-DL40G-N4 ..."Touch" Green LED Faceplate, NEMA 4, Factory install
76-DL40LG-N4 ..."Touch" Large Red LED Faceplate, NEMA 4, Factory install
76-DL40LR-N4 ..."Touch" Large Red LED Faceplate, NEMA 4, Factory install
76-DL40R-N4 ..."Touch" Large Red LED Faceplate, NEMA 4, Factory install
ART-FS-S/D/C ...NRC for artwork & set-up Faceplate/Desc/Co.Logo
ART-FS-S/D ...NRC for artwork & set-up Faceplate/Desc
Install Custom Faceplate per meter - 1 color Install Custom Faceplate per meter - 1 color .Screw Mounting Clips (2 pc) - to screw tighten slide brackets .Metal Surround Case, includes screw mounting clips ART-FS-001 OP-MTI CLIP OP-MTL96X48 OP-N4X/96X48 .96x48mm clear lockable front cover-NEMA 4X, splash proof Prices subject to change without notice.

USER'S RESPONSIBILITY

We are pleased to offer suggestions on the use of our various products either by way of printed matter or through direct contact with our sales/application engineering staff. However, since we have no control over the use of our products once they are shipped, NO WARRANTY WHETHER OF MERCHANTABILITY, FITNESS FOR PURPOSE, OR OTHERWISE is made beyond the repair, replacement, or refund of purchase price at the sole discretion of Texmate. Users shall determine the suitability of the product for the intended application before using, and the users assume all risk and liability whatsoever in connection therewith, regardless of any of our suggestions or statements as to application or construction. In no event shall Texmate's liability, in law or otherwise, be in excess of the purchase price of the product.

Texmate cannot assume responsibility for any circuitry described. No circuit patent or software licenses are implied. Texmate reserves the right to change circuitry, operating software, specifications, and prices without notice at any time.

EXMATE INC

995 Park Center Drive • Vista, CA 92081-8397

Tel: 1-760-598-9899 • USA 1-800-839-6283 • That's 1-800-TEXMATE

Fax: 1-760-598-9828 • Email: sales@texmate.com • Web: www.texmate.com

Texmate has facilities in Japan, New Zealand, Taiwan, and Thailand, We also have authorized distributors throughout the USA and in 28 other countries.

For product details visit www.texmate.com

Local Distributor Address

Copyright © 2003 Texmate Inc. All Rights Reserved